

BEST AVAILABLE COPY

Files from C:\RON\AUTOSPLT\INTENT\INTENT.ZIP

DRL_CMDS.C96	08/29/94
PR_S_I_S.C96	06/30/94
SEL_GEAR.C96	08/19/94
SEQ_SHFT.C96	08/04/94
TRNS_ACT.C96	08/18/94

```

*****
*
*   Unpublished and confidential. Not to be reproduced,
*   disseminated, transferred or used without the prior
*   written consent of Eaton Corporation.
*
*   Copyright Eaton Corporation, 1993-94.
*   All rights reserved.
*
*****
*
*   Filename: drf_cmds.c9v (AutoSplit)
*
*   Description:
*       The functions in this file will perform the required operations
*       for controlling driveline components on the J1939 communication link.
*
*   Part Number: <none>
*
*   $Log: R:\ashift\wcs\drl_cmds.c9v $
*
*   Rev 1.9  25 Feb 1994 16:07:40  schroeder
*   Removed predip's (experimental) BIN 8 ramp off rate--no longer needed.
*   Added condition to predip's torque bumps: timers are frozen until
*   actual_engine_pct_trq responds. Important when engine brakes are on.
*   Made RECOVERY_STEP_TABLE[] a constant value--all ratios used 8%.
*
*   Rev 1.8  21 Feb 1994 15:07:26  schroeder
*   Replaced shiftability_mode with new flag, engine_brake_available.
*
*   Rev 1.7  03 Feb 1994 15:57:28  schroeder
*   Added setting of command_ETC1 to each command function, enabling
*   overspeed during control_engine_predip() and control_engine_sync() and
*   disabling overspeed during all others.
*
*   Rev 1.6  17 Nov 1993 09:50:10  amsallen
*   In the initiate function, net_engine_pct_trq was replaced with
*   act_engine_pct_trq since desired_engine_pct_trq values are in indicated
*   power not net_power. Also the sync_timer timeout was reduced to 100 for
*   down shifts and 200 for upshifts(1 second and 2 seconds) rather than 200
*   for all shifts. Also the delay at 0 torque after a time out was increase
*   from 150msec to 250 msec.
*
*   Rev 1.5  04 Nov 1993 09:16:08  schroeder
*   In RECOVERY_STEP_TABLE[], restored the value for sixth gear to 8%.
*
*   Rev 1.4  02 Nov 1993 09:40:06  schroeder
*   Replaced demand_engine_pct_trq with pct_demand_at_cur_sp. Engine
*   speed limit during torque limit operation changed from high idle to
*   8031 rpm, as suggested in J1939/71.
*
*   Rev 1.3  11 Oct 1993 14:22:40  schroeder
*   Removed cruise_control_active flag; replaced accel pedal with
*   demand_engine_pct_trq.
*
*   Rev 1.2  22 Sep 1993 10:48:22  amsallen
*   The function control_engine_sync was changed to resolve OR 3235ma08.deb,
*   clunky low throttle high range shifts. The engine target now moves above
*   sync when input_speed - sync < 40 rpm and transmission position = engaging
*   rather than just tp = engaging. See OR 3235ma08.deb for additional details.
*
*   Rev 1.1  01 Sep 1993 14:09:52  schroeder
*   In control_engine_sync, modified dither to insure that the engine
*   target stays below sync for a range shift. Also, the dither amount
*   increases from 35rpm to 100rpm, then repeats.
*
*   Rev 1.0  29 Jul 1993 16:40:40  schroeder
*   Initial revision.
*
*****/

/*****
*
*   Header files included.
*
*****/

#include <exec.h>          /* executive information */

```

```

#include <c_regs.h>          /* K1 internal register definitions */
#include <swlib.h>           /* contains common global defines */
#include "cont_sys.h"        /* control system information */
#include "conj1939.h"        /* defines interface to j1939 control module */
#include "drl_cmds.h"        /* driveline commands information */
#include "trn_tbl.h"         /* transmission table data structures */
#include "sel_gear.h"         /* access to speed filter values */
#include "calc_spd.h"
#include "trns_act.h"

#pragma noreentrant

/*****
 *
 * #defines local to this file.
 *
 *****/

#define US_PER_LOOP 10000U

#define ACTIVE_RECOVERY_GEAR 10 /* rule out boosting downs for now */

/*****
 *
 * Constants and variables declared by this file.
 *
 *****/

/* public */

register uchar engine_commands;
register uchar engine_status;
uchar desired_sync_test_mode;
/* uint desired_eng_spd_new; */
/* uint desired_eng_spd_delta; */
/* uint desired_eng_spd_diff; */
uint desired_engine_speed_test;
uint desired_engine_speed_ramp;
uchar desired_engine_speed_timer;
uchar desired_engine_speed_time;
uchar eng_brake_command;
uchar eng_brake_assist;
uchar positive_pedal_trans;
uchar sync_first_pass_timer;
uchar clutch_state;
uint clutch_slip_speed;
int dos_filtered;
int overall_error;
unsigned int os_based_on_rcs;
unsigned int input_speed_filtered;
unsigned long is_filtered_bin8;
unsigned int output_speed_filtered;
unsigned long os_filtered_bin8;
signed int input_speed_accel_filtered;
signed long dis_filtered_bin8;

char eng_percent_torque_filtered;
char percent_torque_accessories;
char needed_percent_for_zero_flywheel_trq;
uchar zero_flywheel_trq_timer;
uchar zero_flywheel_trq_time;
uchar accelerator_pedal_position_old;
int input_shaft_accel_calculated;
uint gos; /* overall destination gear ratio * output speed BIN 0 */
int gos_signed; /* overall destination gear ratio * output speed BIN 0 */

uint gos_current_gear; /* overall current gear ratio * output speed BIN 0 */

unsigned char sync_first_pass;
unsigned int sync_maintain_timer;
signed int sync_offset;
signed int sync_dos_offset;
signed int sync_dos_offset_K1;
signed int sync_speed_modified;
unsigned char intent_to_shift;
char intent_final_pct_trq;
char intent_ramp_off_rate;

/* local */

```

```
static uint predip_timer_1;  
static uchar predip_timer_2;  
static uchar predip_timer_3;  
static char predip_torque_bump_value;  
static uchar predip_torque_bump_time;
```

```
static uint sync_on_timer;  
static uint sync_off_timer;  
static uchar sync_dither_timer;
```

```
static uint torque_limit;  
static uchar recovery_cancel_timer;  
static uint recov_coast_down_tmp1;  
static uint recov_coast_down_tmp2;
```

```
static int dgos;  
static int lpf_output_accel;
```

```
#pragma EJECT
```

```

/*****
 *
 *          PREDIP MODE CONSTANTS
 *
 *****/

#define PREDIP_ZERO_FDBK_TIME      40      /* 0.40s @10ms period */
#define PREDIP_TORQUE_ZERO_TIME    60      /* 0.60s @10ms period */
#define PREDIP_NORMAL_TIME        200     /* 2.00s @10ms period */
#define TORQUE_RAMP_OFF_RATE       1       /* 1% (per loop) */

#define PREDIP_TORQ_BUMP_VALUE_LO   0       /* 0% */
#define PREDIP_TORQ_BUMP_TIME_LO   15     /* 0.15s @10ms period */

#define PREDIP_TORQ_BUMP_VALUE_MED  5       /* 5% */
#define PREDIP_TORQ_BUMP_TIME_MED  25     /* 0.25s @10ms period */

#define PREDIP_TORQ_BUMP_VALUE_HI  10     /* 10% */
#define PREDIP_TORQ_BUMP_TIME_HI   30     /* 0.30s @10ms period */

/*****
 *
 *          SYNC MODE CONSTANTS
 *
 *****/

#define SYNC_DITHER_TIME_ABOVE    20      /* 0.20s @10ms period */
#define SYNC_DITHER_TIME_BELOW    30      /* 0.30s @10ms period */
#define SYNC_DITHER_RPM           35      /* 35 rpm */
#define SYNC_DITHER_FIRST_TIME    255     /* DUMMY VALUE */


#define MAINTAIN_SYNC_TIME         500     /* 5.00 Sec */
#define SYNC_FIRST_PASS_TIME       250     /* 2.50 Sec */
#define THREE_PERCENT              3
#define ENG_RESPONSE_UPSHF_TIME    10     /* 10 msec */
#define ENG_RESPONSE_DNSHF_TIME    10     /* 10 msec */
#define SYNC_DOS_OFFSET_CONSTANT   2816   /* 11 BIN 8 */

/*****
 *
 *          RECOVERY MODE CONSTANTS
 *
 *****/

#define RECOVERY_CANCEL_TIME        10     /* 0.10s @10ms period */
#define RECOVERY_CANCEL_OFFSET      20     /* 20% BIN 0 */
#define RECOVERY_TORQUE_STEP        1280   /* 5% BIN 8 */
#define THLO_DS_ENG_DECAY_K1        450
#define THLO_DS_ENG_DECAY_RAMP      1      /* 1 rpm BIN 0 */
#define THLO_DS_FINISHED_DELTA      200    /* 200 rpm BIN 0 */

static const uint RECOVERY_RATE_TABLE[23] =
(
    0,      /* -4 */
    0,      /* -3 */
    128,    /* -2 : 0.50% per loop BIN 8 */
    128,    /* -1 : 0.50% per loop BIN 8 */
    128,    /* 0 : 0.50% per loop BIN 8 */
    128,    /* 1 : 0.50% per loop BIN 8 */
    128,    /* 2 : 0.50% per loop BIN 8 */
    128,    /* 3 : 0.50% per loop BIN 8 */
    128,    /* 4 : 0.50% per loop BIN 8 */
    192,    /* 5 : 0.75% per loop BIN 8 */
    192,    /* 6 : 0.75% per loop BIN 8 */
    192,    /* 7 : 0.75% per loop BIN 8 */
    281,    /* 8 : 1.10% per loop BIN 8 */
    281,    /* 9 : 1.10% per loop BIN 8 */
    281,    /* 10 : 1.10% per loop BIN 8 */
    0,      /* 11 */
    0,      /* 12 */
    0,      /* 13 */
    0,      /* 14 */
    0,      /* 15 */
    0,      /* 16 */
    0,      /* 17 */
    0       /* 18 */
);

```



```

/*****
 *
 * Function: initialize_driveline_data
 *
 * Description:
 *   This function, called after all resets, will initialize the system
 *   copy of driveline related data received from the communications link.
 *
 *****/

```

```

static void initialize_driveline_data(void)
{
    accelerator_pedal_position = 0;
    engine_communication_active = FALSE;
    engine_brake_available = FALSE;
    eng_brake_command = ENG_BRAKE_IDLE; /* should init with engine_commands */
    clutch_state = ENGAGED;
    positive_pedal_trans = FALSE;
    zero_flywheel_trq_timer = 0;
    zero_flywheel_trq_time = 0;
    percent_torque_accessories = 3;

    desired_sync_test_mode = FALSE; /* debug use only - delete later */
    desired_engine_speed_test = 0; /* debug use only - delete later */
    desired_engine_speed_ramp = 0; /* debug use only - delete later */
    desired_engine_speed = 0;
    /* desired_eng_spd_new = 0; */
    /* desired_eng_spd_diff = 0; */
    /* desired_eng_spd_delta = 10; */
    desired_engine_speed_timer = 0;
    sync_dos_offset_K1 = SYNC_DOS_OFFSET_CONSTANT;
    desired_engine_speed_time = 0;
    intent_to_shift = FALSE;
    intent_final_pct_trq = 0;
    intent_ramp_off_rate = 1;
}

```

```

#pragma EJECT

```

```

/*****
*
* Function: control_engine_predip
*
* Description:
*   Determines throttle command for predip mode.
*
*   After a reasonable delay for the transmission to pull to neutral the
*   torque will be cycled from zero to a determined value to help the
*   transmission achieve neutral.
*
*****/

static void control_engine_predip(void)
(
    if (engine_status != ENGINE_PREDIP_MODE)
    (
        engine_status = ENGINE_PREDIP_MODE;

        predip_timer_1 = 0;
        predip_timer_2 = 0;
        predip_timer_3 = 0;

        if (actual_engine_pct_trq < 5)
            predip_timer_1 = PREDIP_NORMAL_TIME;
        else
            desired_engine_pct_trq = actual_engine_pct_trq;
    )

    engine_control = TORQUE_CONTROL;
    command_ETC1 = C_ETC1_OVERSPEED;

    if (predip_timer_1 < PREDIP_NORMAL_TIME)
    (
        if ((desired_engine_pct_trq >= TORQUE_RAMP_OFF_RATE) &&
            (actual_engine_pct_trq > 0))
        (
            desired_engine_pct_trq -= TORQUE_RAMP_OFF_RATE;
        )
        else
        (
            desired_engine_pct_trq = 0;

            /* check to force bump if neutral not achieved */
            if (actual_engine_pct_trq < 10)
            (
                if (++predip_timer_3 >= PREDIP_ZERO_FDBK_TIME)
                    predip_timer_1 = PREDIP_NORMAL_TIME;
            )
        )
        ++predip_timer_1;
    )
    else
    (
        if ((lpf_output_accel > -150) &&
            (predip_timer_1 < (PREDIP_NORMAL_TIME + PREDIP_TORQUE_ZERO_TIME)))
        (
            predip_torque_bump_time = PREDIP_TORQ_BUMP_TIME_LO;
            predip_torque_bump_value = PREDIP_TORQ_BUMP_VALUE_LO + needed_percent_for_zero_flywheel_trq;
        )
        else
        (
            if (predip_timer_1 < (PREDIP_NORMAL_TIME + 2*PREDIP_TORQUE_ZERO_TIME))
            (
                predip_torque_bump_time = PREDIP_TORQ_BUMP_TIME_MED;
                predip_torque_bump_value = PREDIP_TORQ_BUMP_VALUE_MED + needed_percent_for_zero_flywheel_trq;
            )
            else
            (
                predip_torque_bump_time = PREDIP_TORQ_BUMP_TIME_HI;
                predip_torque_bump_value = PREDIP_TORQ_BUMP_VALUE_HI + needed_percent_for_zero_flywheel_trq;
            )
        )
    )

    if (predip_timer_2 < predip_torque_bump_time)
    (
        desired_engine_pct_trq = predip_torque_bump_value;
        if (actual_engine_pct_trq > 0)
        (

```



```

        ++predip_timer_1;
        ++predip_timer_2;
    }
}
else
{
    desired_engine_pct_trq = 0;
    ++predip_timer_1;
    ++predip_timer_2;
}

if (predip_timer_2 >= PREDIP_TORQUE_ZERO_TIME)
    predip_timer_2 = 0;
}
#pragma EJECT

```

```

/*****
 *
 * Function: control_engine_sync_lever (AutoSplit)
 *
 * Description:
 * This function synchronizes engine speed to output shaft speed
 * during a shift.
 *****/

static void control_engine_sync_lever(void)
(
    if (accelerator_pedal_position > THREE_PERCENT)
        sync_maintain_timer = MAINTAIN_SYNC_TIME;

    if ((engine_status != ENGINE_SYNC_MODE) || (sync_maintain_timer == 0))
    (
        sync_on_timer = 0;
        sync_off_timer = 0;

        if (engine_status != ENGINE_SYNC_MODE) /* first time through sync */
        (
            sync_maintain_timer = MAINTAIN_SYNC_TIME;
            engine_status = ENGINE_SYNC_MODE;
        )
        else /* sync_maintain_timer reached 0 */
        (
            engine_control = OVERRIDE_DISABLED;
            command_ETC1 = C_ETC1_NORMAL;
        )
    )

    else
    (
        sync_maintain_timer--;

        if (sync_on_timer++ <= 296) /* allow sync mode for about 3 SEC */
        (
            sync_off_timer = 0;
            engine_control = SPEED_CONTROL;
            command_ETC1 = C_ETC1_OVERSPEED;

            if (shift_type == UPSHIFT)
            (
                sync_offset = -65; /* RPM */
            )

            else /* shift is a downshift */
            (
                sync_offset = -65; /* RPM */
            )

            if (gos_signed + sync_offset > 0)
            (
                /* desired_engine_speed = (int)(gos_signed + sync_offset); */

                _cx = dos_filtered; /* BIN 0 */
                _bx = trn_tbl.gear_ratio[destination_gear + GR_OFS]; /* BIN 8 */
                _ax = sync_dos_offset_K1; /* BIN 8 */
                asm mul _cxdx, _bx; /* BIN 8 */
                asm div _cxdx, _ax; /* divide by constant BIN 8 */
                sync_dos_offset = _cx; /* save final result BIN 0 */

                desired_engine_speed = (int)(gos_signed + sync_offset + sync_dos_offset);
            )

            #if (0)
                desired_eng_spd_new = (int)(gos_signed + sync_offset);

                if (desired_eng_spd_new > desired_engine_speed)
                    desired_eng_spd_diff = desired_eng_spd_new - desired_engine_speed;
                else
                    desired_eng_spd_diff = desired_engine_speed - desired_eng_spd_new;

                if (desired_eng_spd_diff > desired_eng_spd_delta)
                    desired_engine_speed = desired_eng_spd_new;
            #endif
        )
    )
}

```

```

    )
    else
        desired_engine_speed = 0;
    )
    else
    (
        if (sync_off_timer <= 4)
        (
            sync_off_timer++;
        #if (0)
            engine_control = TORQUE_CONTROL;
            command_ETC1 = C_ETC1_OVERSPEED;
            desired_engine_pct_trq = needed_percent_for_zero_flywheel_trq;
        #endif
    )
    else
        sync_on_timer = 0;
    )
}
}
}

#pragma EJECT

```

```

/*****
 *
 * Function: control_engine_sync_auto    (AutoSplit)
 *
 * Description:
 *   This function synchronizes engine speed to output shaft speed
 *   during a shift.
 *
 *****/

static void control_engine_sync_auto(void)
{
    if (accelerator_pedal_position > THREE_PERCENT)
        sync_maintain_timer = MAINTAIN_SYNC_TIME;

    if ((engine_status != ENGINE_SYNC_MODE) || (sync_maintain_timer == 0))
    {
        sync_on_timer = 0;
        sync_off_timer = 0;
        sync_first_pass = TRUE;
        sync_first_pass_timer = SYNC_FIRST_PASS_TIME;

        if (shift_type == UPSHIFT)
            sync_offset = -65;
        else
            sync_offset = 65;

        if (engine_status != ENGINE_SYNC_MODE) /* first time through sync */
        {
            sync_maintain_timer = MAINTAIN_SYNC_TIME;
            engine_status = ENGINE_SYNC_MODE;
        }
        else /* sync_maintain_timer reached 0 */
        {
            engine_control = OVERRIDE_DISABLED;
            command_ETC1 = C_ETC1_NORMAL;
        }
    }
    else
    {
        sync_maintain_timer--;

        if (sync_on_timer++ <= 200) /* allow sync mode for about 2 seconds */
        {
            sync_off_timer = 0;
            engine_control = SPEED_CONTROL;
            command_ETC1 = C_ETC1_OVERSPEED;

            if (sync_first_pass == TRUE)
            {
                if (shift_type == UPSHIFT)
                {
                    sync_speed_modified = (signed int)(input_speed) +
                        (input_speed_accel_filtered / (1000/ENG_RESPONSE_UPSHF_TIME));

                    if (sync_speed_modified < gos_signed)
                    {
                        if (sync_first_pass_timer == 0)
                        {
                            sync_offset = 65;
                            sync_first_pass = FALSE;
                        }
                        else
                            sync_first_pass_timer--;
                    }
                }
                else /* shift is a downshift */
                {
                    sync_speed_modified = (signed int)(input_speed) +
                        (input_speed_accel_filtered / (1000/ENG_RESPONSE_DNSHF_TIME));

                    if (sync_speed_modified > gos_signed)
                    {
                        /* if (sync_first_pass_timer == 0) */
                        /* { */
                        sync_first_pass = FALSE;
                        if (pct_demand_at_cur_sp < 15)
                            sync_offset = -65;
                    }
                }
            }
        }
    }
}

```

```

/* }
/* else
/* sync_first_pass_timer--;
/*
}
}

if (gos_signed + sync_offset > 0)
    desired_engine_speed = (int)(gos_signed + sync_offset);
else
    desired_engine_speed = 0;
}
else
{
    if (sync_off_timer <= 4)
    {
        sync_off_timer++;
    }
    #if (0)
        engine_control = TORQUE_CONTROL;
        command_ETC1 = C_ETC1_OVERSPEED;
        desired_engine_pct_trq = needed_percent_for_zero_flywheel_trq;
    #endif
}
else
{
    sync_on_timer = 0;
    sync_offset = -(sync_offset); /* force sync speed to toggle around gos */
}
}
}
}
#pragma EJECT

```

```

/*****
 *
 * Function: control_engine_sync (AutoSplit)
 *
 * Description:
 *   This function synchronizes engine speed to output shaft speed
 *   during a shift.
 *
 *****/

```

```
static void control_engine_sync(void)
```

```
{
    if (shift_init_type == AUTO)
        control_engine_sync_auto();
    else
        control_engine_sync_lever();

    intent_to_shift = FALSE;

```

```
}
```

```
#pragma EJECT
```

```

/*****
 *
 * Function: control_engine_sync_test_mode (AutoSplit)
 *
 * Description:
 * This function test the synchronize mode of engine speed control.
 *
 *****/

static void control_engine_sync_test_mode(void)
(
    if (accelerator_pedal_position < 10)
    (
        engine_status = ENGINE_FOLLOWER_MODE;
        engine_commands = ENGINE_FOLLOWER;
        engine_control = OVERRIDE_DISABLED;
        command_ETC1 = C_ETC1_NORMAL;
        desired_engine_speed = 0;
    )
    else
    (
        if (accelerator_pedal_position > 90)
        (
            engine_status = ENGINE_SYNC_MODE;
            engine_commands = ENGINE_SYNC;
            engine_control = SPEED_CONTROL;
            command_ETC1 = C_ETC1_OVERSPEED;
            desired_engine_speed = desired_engine_speed_test;
            desired_engine_speed_timer = desired_engine_speed_time;
        )
        else
        (
            if (desired_engine_speed_timer > 0)
                desired_engine_speed_timer--;
            else
            (
                if (desired_engine_speed > 600)
                (
                    desired_engine_speed_timer = desired_engine_speed_time;
                    desired_engine_speed = (desired_engine_speed - desired_engine_speed_ramp);
                )
            )
        )
    )
)
#pragma EJECT

```

```

/*****
*
* Function:  determine_if_recovery_complete
*
* Description:
*   This routine checks to see if the percent_torque_value_limit has
*   exceeded the percent_torque_value feedback from the engine by x%
*   for x milliseconds and will then set percent_torque_value_limit
*   to 100% to cancel the recovery mode.
*
*****/

static void determine_if_recovery_complete(void)
{
    if ((net_engine_pct_trq > 10) &&
        (desired_engine_pct_trq > (net_engine_pct_trq + RECOVERY_CANCEL_OFFSET)))
    {
        ++recovery_cancel_timer;
    }
    else
        recovery_cancel_timer = 0;

    if ( (recovery_cancel_timer >= RECOVERY_CANCEL_TIME) ||
        (desired_engine_pct_trq == 100) )
    {
        /* terminate the recovery mode */
        desired_engine_pct_trq = 100;
        engine_status = ENGINE_RECOVERY_MODE_COMPLETE;
    }
}

#pragma EJECT

```



```

/*****
*
* Function: control_engine_recovery_normal
*
* Description:
*   Determine throttle command for recovery mode.
*   TORQUE_LIMIT is scaled as a BIN 8 number representing the percentage
*   of torque allowed to the engine during recovery.
*
*****/

static void control_engine_recovery_normal(void)
{
    engine_control = SPEED_TORQUE_LIMIT;
    command_ETC1 = C_ETC1_NORMAL;

    desired_engine_speed = 8031; /* torque limit only, max value for speed */

    torque_limit += RECOVERY_RATE_TABLE[destination_gear+4]; /* BIN 8 */

    desired_engine_pct_trq = (char)(torque_limit >> 8); /* BIN 0 */

    determine_if_recovery_complete();
}

#pragma EJECT

```

```

/*****
 *
 * Function: control_engine_recovery_coasting
 *
 * Description:
 *   Determine throttle command for coasting down shifts mode.
 *
 *****/

static void control_engine_recovery_coasting(void)
(
    register uint local_uint;

    if (sync_on_timer <= 300)
    (
        ++sync_on_timer;

        engine_control = SPEED_CONTROL;
        command_ETC1 = C_ETC1_NORMAL;

        sync_off_timer = 0;

        /** recov_coast_down_tmp1 = gos + (dgos * K1) - THLO_DS_ENG_DECAY_RAMP **/

        if (dgos < 0)          /* get absolute value */
            _cx = (uint)-dgos;
        else
            _cx = (uint)dgos;

        asm mulu _cxdx, #THLO_DS_ENG_DECAY_K1;    /* BIN 12 */
        asm shrl _cxdx, #12;                      /* BIN 0 */

        if (_cxdx > 500)                /* error check */
            local_uint = 0;
        else
            local_uint = _cx;

        if (lpf_output_accel > 0)
            recov_coast_down_tmp1 = (gos + local_uint) - THLO_DS_ENG_DECAY_RAMP;
        else
            recov_coast_down_tmp1 = (gos - local_uint) - THLO_DS_ENG_DECAY_RAMP;

        /** recov_coast_down_tmp2 = desired_engine_speed - THLO_DS_ENG_DECAY_RAMP **/

        recov_coast_down_tmp2 = desired_engine_speed - THLO_DS_ENG_DECAY_RAMP;

        if (recov_coast_down_tmp1 < recov_coast_down_tmp2)
            desired_engine_speed = recov_coast_down_tmp1;
        else
            desired_engine_speed = recov_coast_down_tmp2;
    )
    else
    (
        if (sync_off_timer <= 5)
        (
            ++sync_off_timer;
            engine_control = TORQUE_CONTROL;
            command_ETC1 = C_ETC1_NORMAL;
            desired_engine_pct_trq = 0;
        )
        else
            sync_on_timer = 0;
    )

    if ((desired_engine_speed + THLO_DS_FINISHED_DELTA) < gos)
    (
        /* terminate the recovery mode */
        desired_engine_pct_trq = 100;
        engine_status = ENGINE_RECOVERY_MODE_COMPLETE;
    )
)

```

```
#pragma EJECT
```

```

/*****
 *
 * Function: control_engine_recovery
 *
 * Description:
 *   This function determines which type of throttle recovery should be
 *   used. And initializes some of the variables that will be used.
 *
 *****/

static void control_engine_recovery(void)
(
    if ((engine_status != ENGINE_RECOVERY_MODE) &&
        (engine_status != ENGINE_RECOVERY_MODE_COMPLETE))
    (
        engine_status = ENGINE_RECOVERY_MODE;
        desired_engine_pct_trq = 0;
        recovery_cancel_timer = 0;
        sync_on_timer = 0;
        sync_off_timer = 0;

        /* kill pedal transition stuff */
        positive_pedal_trans = FALSE;
        positive_pedal_trans = FALSE;
        zero_flywheel_trq_timer = 0;
        zero_flywheel_trq_time = 0;

        if (gos < desired_engine_speed)
            desired_engine_speed = gos;

        /* set initial starting torque limit */      /* percent, BIN 8 */
        if ((actual_engine_pct_trq > needed_percent_for_zero_flywheel_trq) &&
            (pct_demand_at_cur_sp > 5))
            torque_limit = ((unsigned int)(actual_engine_pct_trq))<<8; /* percent, BIN 8 */
        else
            torque_limit = ((unsigned int)(needed_percent_for_zero_flywheel_trq))<<8; /* percent, BIN 8 */
    )

    if ((destination_gear > ACTIVE_RECOVERY_GEAR) &&
        (pct_demand_at_cur_sp < 5) &&
        ((shift_type == COAST_DOWN_SHIFT) ||
         (shift_type == UPSHIFT)))
    (
        control_engine_recovery_coasting();
    )
    else
    (
        control_engine_recovery_normal();
    )
)
#pragma EJECT

```

```

/*****
 *
 * Function: control_intent_to_shift
 *
 * Description:
 *   This function
 *
 *****/

```

```

static void control_intent_to_shift(void)
{
    if (engine_control != TORQUE_CONTROL)
    {
        desired_engine_pct_trq = actual_engine_pct_trq;
    }

    engine_control = TORQUE_CONTROL;
    command_ETC1 = C_ETC1_OVERSPEED;

    positive_pedal_trans = TRUE; /* allow for recovery mode */

    if ((desired_engine_pct_trq >= intent_ramp_off_rate) &&
        (actual_engine_pct_trq > intent_final_pct_trq))
    {
        desired_engine_pct_trq -= intent_ramp_off_rate;
    }
    else
    {
        desired_engine_pct_trq = intent_final_pct_trq;
    }
}

#pragma EJECT

```

```

/*****
 *
 * Function: control_engine_follower
 *
 * Description:
 *   This function sets the override_control_mode to no over ride so that
 *   the engine follows the accelerator demand.
 *
 *****/

static void control_engine_follower(void)
(
#define POSITIVE_PEDAL_TRANSITION_TIME 25 /* 250 MSEC */
#define NEGATIVE_PEDAL_TRANSITION_TIME 40 /* 400 MSEC */

    engine_status = ENGINE_FOLLOWER_MODE;

    if ((intent_to_shift == TRUE) &&
        (shift_in_process == FALSE) &&
        (desired_gear != destination_gear_selected))
    (
        control_intent_to_shift();
    )

    else
    (
        if ((accelerator_pedal_position >= 5) && /* positive pedal transition */
            (accelerator_pedal_position_old <= 4) &&
            (low_speed_latch == FALSE))
        (
            positive_pedal_trans = TRUE;
            zero_flywheel_trq_time = POSITIVE_PEDAL_TRANSITION_TIME;
            if (zero_flywheel_trq_timer >= NEGATIVE_PEDAL_TRANSITION_TIME)
                zero_flywheel_trq_timer = 0;
        )

        else
        (
            if ((accelerator_pedal_position <= 4) && /* negative pedal transition */
                (accelerator_pedal_position_old >= 5) &&
                (low_speed_latch == FALSE))
            (
                zero_flywheel_trq_time = NEGATIVE_PEDAL_TRANSITION_TIME;
                zero_flywheel_trq_timer = 0;
            )
        )

        if ((zero_flywheel_trq_timer < zero_flywheel_trq_time) &&
            (current_gear > 1) && (current_gear < 10) && (low_speed_latch == FALSE))
        (
            engine_control = TORQUE_CONTROL;
            command_ETC1 = C_ETC1_OVERSPEED;
            desired_engine_pct_trq = needed_percent_for_zero_flywheel_trq;

            if (actual_engine_pct_trq < (needed_percent_for_zero_flywheel_trq + 5));
                zero_flywheel_trq_timer++;
        )

        else
        (
            if ((positive_pedal_trans == TRUE) && (low_speed_latch == FALSE))
            (
                positive_pedal_trans = FALSE;
                engine_commands = ENGINE_RECOVERY; /* engine: finish torque return */
                control_engine_recovery();
            )

            else
            (
                engine_control = OVERRIDE_DISABLED;
                command_ETC1 = C_ETC1_NORMAL;
            )
        )
    ) /* end no intent_to_shift */
)

#pragma EJECT

```

```
/*
 *
 * Function: control_engine_idle
 *
 * Description:
 *   This function sets the engine controls for the idle mode.
 *
 */
```

```
static void control_engine_idle(void)
{
    engine_control = OVERRIDE_DISABLED;
    command_ETC1 = C_ETC1_NORMAL;

    engine_status = ENGINE_IDLE_MODE;
}
```

```
#pragma EJECT
```

```

/*****
 *
 * Function: control_engine_start
 *
 * Description:
 *   This function sets the engine controls for the start mode.
 *
 *****/

```

```

static void control_engine_start(void)
{
    engine_control = OVERRIDE_DISABLED;
    command_ETC1 = C_ETC1_NORMAL;

    engine_status = ENGINE_START_MODE;
}

```

```

#pragma EJECT

```

```

/*****
 *
 * Function: control_engine_compression_brake
 *
 * Description:
 *   This function controls the state of the engine compression brake.
 *   The brake can be used during upshifts to speed up the decel rate of
 *   the input shaft.
 *
 *****/

```

```

static void control_engine_compression_brake(void)
{
    if (engine_communication_active &&
        (engine_status == ENGINE_SYNC_MODE) &&
        (shift_type == UPSHIFT) &&
        (input_speed_filtered > (gos + 150)) &&
        (destination_gear > 1) &&
        (destination_gear < 7) &&
        (engine_brake_available) &&
        ((dos_predicted < dos_prdtd_lim_no_jake) || eng_brake_assist))
    {
        eng_brake_assist = TRUE;
    }
    else
    {
        eng_brake_assist = FALSE;
    }

    eng_brake_assist = FALSE; /* force false state for now */
}

```

```

#pragma EJECT

```



```

/*****
 *
 * Function:  determine_gos
 *
 * Description:
 *   This function multiplies the destination gear ratio times the
 *   output shaft speed for use in the DRL_CMDS module.
 *
 *   gos = (g)ear * (o)utput (s)peed
 *
 *****/

static void determine_gos(void)
(
  /*** determine gos for the destination_gear ***/
  _bx = trn_tbl.gear_ratio[destination_gear + GR_OFS];
  _cx = output_speed_filtered; /* output speed */
  asm mulu _cxdx, _bx;          /* BIN 8 result */
  asm shrl _cxdx, #8;           /* make BIN 0 */
  gos = _cx;                    /* BIN 0 */

  _cx = *(uint *)&lpf_output_accel;
  asm mul _cxdx, _bx;
  asm div _cxdx, #256;
  dgos = *(int *)&_cx;

  gos_signed = (signed int)(gos); /* allow signed math in other functions*/

  /*** determine gos for the "current_gear" ***/
  _bx = trn_tbl.gear_ratio[current_gear + GR_OFS];
  _cx = output_speed_filtered; /* output speed */
  asm mulu _cxdx, _bx;          /* BIN 8 result */
  asm shrl _cxdx, #8;           /* make BIN 0 */
  gos_current_gear = _cx;       /* BIN 0 */
)

#pragma EJECT

```

```

/*****
 *
 * Function:  determine_shiftability_variables
 *
 * Description:
 *   This function filters both the output speed and the rate of change of
 *   the output speed for use in the shiftability function. This function
 *   also calculates the rate of change of the input shaft based on the
 *   filtered value for the rate of change of the output shaft.
 *
 *   The filters used in this function are required to get a high level of
 *   stability. The BIN 8 filter used here will provide a much smoother
 *   output which is needed to filter out driveline oscillations.
 *
 *   Note: These calculations were placed in this module because it is
 *   called on a regular 10 msec interval. These calculations should
 *   be placed in the pr_i_s_i.c96 module once shiftability is proven.
 *   These variables are used in the SEL_GEAR.C96 module.
 *****/

```

```

static void determine_shiftability_variables(void)
(

```

```

/* LPF coefficients: exp(-wT), T=0.010s */
#define OS_LPF      248      /* 0.9691 BIN 8 (0.50Hz) */
#define DOSFK1      249      /* 0.9727 BIN 8 (0.44Hz) */
#define EPTFK1      252      /* 0.9844 BIN 8 (0.25Hz) */

#define IS_FK1      236      /* 0.9219 BIN 8 (0.??Hz) */
#define OS_FK1      236      /* 0.9219 BIN 8 (0.??Hz) */
#define DISFK1      236      /* 0.9219 BIN 8 (0.??Hz) */

#define LOW_RANGE    3197     /* 3.1224 BIN 10 */
#define BIN_10       1024

```

```

static long dos_filtered_bin8;
static int ept_filtered_bin8;

```

```

unsigned long is_filtered_partial_1;
unsigned long is_filtered_partial_2;
unsigned long os_filtered_partial_1;
unsigned long os_filtered_partial_2;

```

```

/** create lpf_output_accel */

```

```

_bx = *(uint *)&output_speed_accel;          /* _bx = x(n), BIN 0 */
_cx = *(uint *)&lpf_output_accel - _bx;      /* _cx = y(n-1) - x(n), BIN 0 */
asm mul _cxdx, #OS_LPF;                       /* _cxdx = K*(...), BIN 8 */
asm div _cxdx, #256;                           /* make BIN 0 */
_bx += _cx;                                   /* _bx = x(n) + K*(...), BIN 0 */
lpf_output_accel = *(int *)&_bx;              /* save acceleration */

```

```

/** dos_filtered = (dos_filtered * DOSFK1) + (lpf_output_accel * (1-DOSFK1)) */

```

```

_cxdx = *(ulong *)&dos_filtered_bin8;        /* BIN 8 */
asm shral _cxdx, #2;                          /* BIN 6 (_cx) */
asm mul _cxdx, #DOSFK1;                       /* BIN 14 */
asm shral _cxdx, #6;                          /* BIN 8 */
dos_filtered_bin8 = *(long *)&_cxdx;          /* save partial result */

```

```

_cx = *(uint *)&lpf_output_accel;            /* BIN 0 */
_bx = 256 - DOSFK1;                          /* 1 BIN 8 - DOSFK1 */
asm mul _cxdx, _bx;                          /* BIN 8 */
dos_filtered_bin8 += *(long *)&_cxdx;         /* sum is final result */

```

```

dos_filtered = (int)(dos_filtered_bin8 >> 8); /* BIN 0 */

```

```

/** eng_percent_torque_filtered = (eng_percent_torque_filtered * EPTFK1) +
    (net_engine_pct_trq * (1-EPTFK1)) */

```

```

_cx = *(uint *)&ept_filtered_bin8;           /* BIN 8 */
asm mul _cxdx, #EPTFK1;                      /* BIN 16 */
asm shral _cxdx, #8;                         /* BIN 8 */
ept_filtered_bin8 = *(int *)&_cx;            /* save partial result */

```

```

_cx = net_engine_pct_trq;                    /* BIN 0 */
_bx = 256 - EPTFK1;                          /* 1 BIN 8 - EPTFK1 */
asm mul _cxdx, _bx;                          /* BIN 8 */
ept_filtered_bin8 += *(int *)&_cx;           /* sum is final result */

```

```

eng_percent_torque_filtered = (char)(ept_filtered_bin8 >> 8);

/** input_shaft_accel_calculated = dos_filtered * gear_ratio */

_cx = trn_tbl.gear_ratio[destination_gear + GR_OFS]; /* BIN 8 */
_bx = *(uint *)&dos_filtered; /* BIN 0 */
asm mul_cxdx, _bx; /* BIN 8 */
asm shrl_cxdx, #8; /* BIN 0 */
input_shaft_accel_calculated = *(int *)&_cx;

/** calculate filtered input and output shaft speeds for AutoSplit */

/** determine os_based_on_rcs variable */
if (output_speed < 1000)
{
    _bx = aux_speed; /* BIN 0 */
    _cx = BIN_10; /* BIN 10 */
    _ax = LOW_RANGE; /* BIN 10 */
    asm mulu_cxdx, _bx; /* make aux_speed BIN 10 */
    asm divu_cxdx, _ax; /* divide by low range BIN 10 */
    os_based_on_rcs = _cx; /* BIN 0 */
}

/** input_speed_filtered = (input_speed_filtered * IS_FK1) +
    (input_speed * (1-IS_FK1)) */

_ax = (is_filtered_bin8 >> 4); /* BIN 4 */
_cx = IS_FK1; /* BIN 8 */
asm mulu_axbx, _cx; /* BIN 12 */
asm shrl_axbx, #4; /* BIN 8 */
is_filtered_partial_1 = _axbx; /* BIN 8 */

_cx = input_speed; /* BIN 0 */
_ax = 256 - IS_FK1; /* 1 BIN 8 - IS_FK1 */
asm mulu_axbx, _cx; /* BIN 8 */
is_filtered_partial_2 = _axbx; /* BIN 8 */

is_filtered_bin8 = is_filtered_partial_1 + is_filtered_partial_2;

input_speed_filtered = (unsigned int)(is_filtered_bin8 >> 8); /* BIN 0 */

/** output_speed_filtered = (output_speed_filtered * OS_FK1) +
    (output_speed * (1-OS_FK1)) */

_ax = (os_filtered_bin8 >> 4); /* BIN 4 */
_cx = OS_FK1; /* BIN 8 */
asm mulu_axbx, _cx; /* BIN 12 */
asm shrl_axbx, #4; /* BIN 8 */
os_filtered_partial_1 = _axbx; /* BIN 8 */

if (output_speed < 250)
    _cx = os_based_on_rcs; /* BIN 0 */
else
    _cx = output_speed; /* BIN 0 */

_ax = 256 - OS_FK1; /* 1 BIN 8 - OS_FK1 */
asm mulu_axbx, _cx; /* BIN 8 */
os_filtered_partial_2 = _axbx; /* BIN 8 */

os_filtered_bin8 = os_filtered_partial_1 + os_filtered_partial_2;

output_speed_filtered = (unsigned int)(os_filtered_bin8 >> 8); /* BIN 0 */

/** input_speed_accel_filtered = (input_speed_accel_filtered * DISFK1) + (input_shaft_accel * (1-DISFK1)) */

_cxdx = *(ulong *)&dis_filtered_bin8; /* BIN 8 */
asm shrl_cxdx, #4; /* BIN 4 (_cx) */
asm mul_cxdx, #DISFK1; /* BIN 12 */
asm shrl_cxdx, #4; /* BIN 8 */
dis_filtered_bin8 = *(long *)&_cxdx; /* save partial result */

_cx = *(uint *)&input_speed_accel; /* BIN 0 */
_bx = 256 - DISFK1; /* 1 BIN 8 - DISFK1 */
asm mul_cxdx, _bx; /* BIN 8 */
dis_filtered_bin8 += *(long *)&_cxdx; /* sum is final result */

input_speed_accel_filtered = (int)(dis_filtered_bin8 >> 8); /* BIN 0 */

```

```

/** determine state of clutch **/

if (engine_speed > input_speed)
    clutch_slip_speed = engine_speed - input_speed;
else
    clutch_slip_speed = input_speed - engine_speed;

if (clutch_slip_speed > 200)
    clutch_state = DISENGAGED;
else
    if ((engine_speed > 800) && (low_speed_latch == FALSE))
        clutch_state = ENGAGED;

/** determine desired percent torque needed for zero torque at flywheel **/

#if (0)
if ((accelerator_pedal_position < 2) &&
    (clutch_state == ENGAGED) &&
    (current_gear == 0) &&
    (input_speed_filtered < 1100) &&
    ((engine_control == OVERRIDE_DISABLED) &&
    (low_speed_latch == FALSE) && (current_gear == 0)) ||
    (output_speed_filtered < 20)))
    percent_torque_accessories = eng_percent_torque_filtered; /* get at idle */
#endif
percent_torque_accessories = 3; /* force value for now */

needed_percent_for_zero_flywheel_trq = percent_torque_accessories +
    nominal_friction_pct_trq;

overall_error = ((signed int)(input_speed_filtered) - (signed int)(gos));
)

```

#pragma EJECT

$$\text{fly-wheel torque} = \text{gross engine torque} - \left(\text{base engine friction torque} + \text{engine air drag torque} + \text{engine mechanical torque} \right)$$

equivalent to col. 4.10.3 of 1477

calc.
for zero
torque
pedal-mat

calc.
for zero
torque
pedal-mat

friction
at fly
engine

```

/*****
*
* Function: communicate_with_driveline
*
* Description:
*   This is the periodic task which controls the actions of the engine
*   by defining mode of control and controlling speed and torque output
*   levels depending upon the control function being performed. This task
*   is also intended for control of other driveline components (not yet
*   named) which may be available in the future.
*
*****/

void communicate_with_driveline(void)
(
    initialize_driveline_data();

    x_start_periodic();
    while (1)
    (
        control_engine_compression_brake();

        determine_gos(); /* calculate (G)ear times the (O)utput (S)haft */

        determine_shiftability_variables();

        if (engine_communication_active)
        (
            if ((desired_sync_test_mode == TRUE) && (output_speed_filtered < 100))
                control_engine_sync_test_mode();

            else
            (
                /* start of normal engine_commands switch */

                switch (engine_commands)
                (
                    case ENGINE_PREDIP:
                        control_engine_predip();
                        break;

                    case ENGINE_SYNC:
                        control_engine_sync();
                        break;

                    case ENGINE_RECOVERY:
                        control_engine_recovery();
                        break;

                    case ENGINE_IDLE:
                        control_engine_idle();
                        break;

                    case ENGINE_START:
                        control_engine_start();
                        break;

                    case ENGINE_FOLLOWER:
                    default:
                        control_engine_follower();
                        break;
                )
            ) /* end of normal engine_commands switch */

            switch (eng_brake_command)
            (
                case ENG_BRAKE_OFF:
                    retarder_control = TORQUE_CONTROL;
                    desired_retarder_pct_trq = 0;
                    break;

                case ENG_BRAKE_FULL:
                    retarder_control = TORQUE_CONTROL;
                    desired_retarder_pct_trq = -100;
                    break;

                case ENG_BRAKE_IDLE:
                default:
                    retarder_control = OVERRIDE_DISABLED;

```

```
desired_retarder_pct_trq = 0;  
break;
```

```
}
```

```
else
```

```
engine_status = ENGINE_NOT_PRESENT;
```

```
/* store old value for use in "control_engine_follower" function */  
accelerator_pedal_position_old = accelerator_pedal_position;
```

```
x_sync_periodic(US_PER_LOOP);
```

```
}
```

```
x_end_periodic();  
}
```

```

/*****
*
* Unpublished and confidential. Not to be reproduced,
* disseminated, transferred or used without the prior
* written consent of Eaton Corporation.
*
* Copyright Eaton Corporation, 1994
* All rights reserved.
*
*****/

*
* Filename: pr_s_i_s.c96 (AutoSplit)
*
* Description:
* The modules contained within this compilation unit are
* intended to implement functionality of the Process System
* Input Signals task defined in the design documentation.
* In general, Analog to digital conversions are started on
* Port0. The necessary hardware initialization and variable
* initialization for inputs on Port0 are handled. The switch
* inputs are captured to avoid conflict with AD conversions
* and all necessary scaling and error check for these inputs
* is conducted.
*
* Part Number: <none>
*
* $Log: ?
*
* Rev 1.1 19 May 1994 11:32:26 markyvech
* Converted for use with AutoSplit ECU2
*
* Rev 1.0 12 Sep 1991 08:04:26 amsallen
* Initial revision.
*
*****/

/*****
*
* Header files included.
*
*****/

#include <exec.h> /* executive information */
#include <kr_sfr.h> /* KR special function registers */
#include <kr_def.h> /* KR definitions */
#include <c_regs.h> /* KR internal register definitions */
#include <wwslib.h> /* world wide software definitions */
#include "pr_s_i_s.h" /* process system input signal information */
#include "sysgen.h" /* defines the task names and priority */

/*****
*
* #defines local to this file.
*
*****/

/* Start_AD_Conversions */

#define ENABLE_AD_PTS_SCAN 0X20
#define ENABLE_AD_ISR 0X20

#define PERIOD 10U /* 10ms */
#define RKM_PERIOD 50U /* 50ms */

/*****
*
* Constants and variables declared by this file.
*
*****/

/* Analog Inputs on Port0 */

int ignition_volts;
int splitter_position;

#define IGNITION_VOLTS_CHANNEL_RESULT 1

```

```

#define SPLITTER_POS_CHANNEL_RESULT    15

#define CONVERSION_TIME 0xef           /* for state time = 125 nsec: */
/* sample time = 3.6250 usec */
/* convert time = 20.1875 usec */
#define CONVERT_8 8                    /* scan and convert 8 channels */

#define CONVERT_IGNITION_VOLTS         (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_0)
#define UNUSED_CHANNEL_1              (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_1)
#define UNUSED_CHANNEL_2              (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_2)
#define UNUSED_CHANNEL_3              (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_3)
#define UNUSED_CHANNEL_4              (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_4)
#define UNUSED_CHANNEL_5              (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_5)
#define UNUSED_CHANNEL_6              (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_6)
#define CONVERT_SPLITTER_POS          (_NORM_MODE | _10_BIT_MODE | _STRT_CONV | _CHNL_7)
#define STOP_CONVERSION               0x00
#define START_CONVERSIONS              _ad_command = CONVERT_IGNITION_VOLTS

/* table containing AD_result and AD_Command values after PTS scan */
unsigned int AD_Table[16];

/* AD SCAN PTS CONTROL BLOCK LOCATION */
_ad_ptsb_type AD_Con_Block;
#pragma locate(AD_Con_Block=0x01F8) /* locate pts control block */
#pragma pts(AD_Con_Block = 5)       /* set pts vector 5, A/D done */

#pragma eject

```



```

/*****
*
* Function: Initialize_Input_Signals
*
* Description:
*   This routine initializes the A/D converter. It sets the A/D to
*   run in PTS scan mode, 10bit conversion. The PTS control block is
*   set up and the Command/result table is initialized.
*
*****/

void Initialize_Input_Signals(void)
{
    /* if we knew when the first speed packet arrived, we could initialize
       with those values. since we don't, be safe and use zero. */

    AD_Table[0] = UNUSED_CHANNEL_1;      /* place holder for channel 1 */
    AD_Table[1] = 0x0000;                 /* IGNITION_VOLTS_CHANNEL_RESULT */
    AD_Table[2] = UNUSED_CHANNEL_2;      /* place holder for channel 2 */
    AD_Table[3] = 0x0000;                 /* UNUSED_1_RESULT */
    AD_Table[4] = UNUSED_CHANNEL_3;      /* place holder for channel 3 */
    AD_Table[5] = 0x0000;                 /* UNUSED_2_RESULT */
    AD_Table[6] = UNUSED_CHANNEL_4;      /* place holder for channel 4 */
    AD_Table[7] = 0x0000;                 /* UNUSED_3_RESULT */
    AD_Table[8] = UNUSED_CHANNEL_5;      /* place holder for channel 5 */
    AD_Table[9] = 0x0000;                 /* UNUSED_4_RESULT */
    AD_Table[10] = UNUSED_CHANNEL_6;     /* place holder for channel 6 */
    AD_Table[11] = 0x0000;                 /* UNUSED_5_RESULT */
    AD_Table[12] = CONVERT_SPLITTER_POS; /* Command convert splitter pos */
    AD_Table[13] = 0x0000;                 /* UNUSED_6_RESULT */
    AD_Table[14] = STOP_CONVERSION;      /* command to Stop conversions */
    AD_Table[15] = 0x0000;                 /* SPLITTER_POS_CHANNEL_RESULT */

    AD_Con_Block.cnt = CONVERT_8;
    AD_Con_Block.ctrl = _AD_MODE | _S_D_UPDT; /* A/D mode bits 0,1 of PTS_CONTROL */
                                              /* always set to 3h bit 2 = 0 */
                                              /* S/D update at end of cycle */
                                              /* bit 5 always 0 */
                                              /* Set mode for AD SCAN */

    AD_Con_Block.s_d = AD_Table;          /* Load s_d with AD_Table address */
    AD_Con_Block.reg = (void *)&_ad_result; /* Load reg with AD_Result address */

    _ad_time = CONVERSION_TIME;
    _ad_test = _NO_OFFS;                  /* Disable test mode */
    _pts_select &= ~(_PTS_ADDONE_BIT);    /* Disable AD PTS */
}

#pragma eject

```

```

/*****
 *
 * Function: AD_ISR
 *
 * Description:
 *   This interrupt service routine resets the PTSCOUNT, pts_sd and pts_reg
 *   for another PTS_Scan A/D cycle. It also readies a task to run when
 *   a PTS cycle has completed.
 *
 *****/

#pragma interrupt(AD_ISR=5)
void AD_ISR(void)
{
    x_start_isr();
    AD_Con_Block.cnt = CONVERT_8;          /* Reset pts count for next cycle */
    AD_Con_Block.s_d = AD_Table;          /* Reset table pointer to start of table */
    AD_Con_Block.reg = (void *)&_ad_result;

    x_ready(PROCESS_INPUT_SIGNALS);        /* Ready pr_s_i_s task */
    x_end_isr();
}

#pragma eject

```

```

/*****
*
* Function: Start_AD_Conversions
*
* Description:
* This function initializes the input signal processing function
* if it has not already been done, and then starts the PTS Scan
* of the AD channels by sending the appropriate command to the
* ad_command register.
*
*****/

void Start_AD_Conversions(void)
{
    if ((_int_mask & ENABLE_AD_ISR) == 0 )
        Initialize_Input_Signals();          /* Set up AD table for PTS */

    _pts_select |= ENABLE_AD_PTS_SCAN;
    _int_mask |= ENABLE_AD_ISR;

    x_prearm_stimulus();

    START_CONVERSIONS; /* Start a conversion, initiate the PTS cycles */

    x_wait_stimulus(); /* AD_ISR will ready task when PTS is complete */
}

#pragma eject

```

```

/*****
*
* Function: process_input_signals
*
* Description:
*   This is the periodic task which starts the analog conversions on Port0.
*
*****/

void process_input_signals(void)
{
    x_start_periodic();
    while (1)
    {
        Start_AD_Conversions();

        /* Clean up and scale AD values */
        ignition_volts = scale_system_ad_inputs(IGNITION_VOLTAGE);
        splitter_position = scale_system_ad_inputs(SPLITTER_POSITION);

        /* x_sync_periodic(PERIOD*1000); */
        x_sync_periodic(RKM_PERIOD*1000);
    }
    x_end_periodic();
}

#pragma eject

```

```

/*****
*
* Function: scale_system_ad_inputs
*
* Description:
*   This function removes the channel, status and reserved bits from
*   the raw AD values, and performs all necessary scaling and error
*   checking for the analog inputs on Port0.
*
*****/

```

```

int scale_system_ad_inputs(char Channel)
(
    int Scaled_Value = 0;
    uint volts_per_bit;    /* BIN 16 */
    uint units_per_bit;    /* BIN 16 */
    #define TWELVE_VOLT_FULL_SCALE    22.46 /* volts */
    #define TWENTY_FOUR_VOLT_FULL_SCALE    40.49 /* volts */
    #define DISTANCE_FULL_SCALE    100 /* */

    volts_per_bit = (uint)((TWELVE_VOLT_FULL_SCALE*65536/1023)+0.5);
    units_per_bit = (uint)((DISTANCE_FULL_SCALE*65536/1023)+0.5);

    switch (Channel)
    (
        case 0: /* IGNITION VOLTAGE */
            _cx = AD_Table[IGNITION_VOLTS_CHANNEL_RESULT] >> 6;
            asm mulu _cxdx, volts_per_bit; /* volts, BIN 16 (_dx, BIN 0) */
            Scaled_Value = *(int *)&_dx;
            break;

        case 1: /* UNUSED */ /* to be completed when a product requires it */
            Scaled_Value = (0);
            break;

        case 2: /* UNUSED */ /* to be completed when a product requires it */
            Scaled_Value = (0);
            break;

        case 3: /* UNUSED */ /* to be completed when a product requires it */
            Scaled_Value = (0);
            break;

        case 4: /* UNUSED */ /* to be completed when a product requires it */
            Scaled_Value = (0);
            break;

        case 5: /* UNUSED */ /* to be completed when a product requires it */
            Scaled_Value = (0);
            break;

        case 6: /* UNUSED */ /* to be completed when a product requires it */
            Scaled_Value = (0);
            break;

        case 7: /* SPLITTER POSITION */
            _cx = AD_Table[SPLITTER_POS_CHANNEL_RESULT] >> 6;
            asm mulu _cxdx, units_per_bit; /* distance, BIN 16 (_dx, BIN 0) */
            Scaled_Value = *(int *)&_dx;
            break;

        default:
            break;
    )
    return (Scaled_Value);
)

```

```

/*****
*
*      Unpublished and confidential. Not to be reproduced,
*      disseminated, transferred or used without the prior
*      written consent of Eaton Corporation.
*
*      Copyright Eaton Corporation, 1993-94.
*      All rights reserved.
*
*****/

* Filename:  sel_gear.c96      (AutoSplit)
*
* Description:
* This module is the periodic task "select_gear". It assigns values
* to destination_gear_selected as a function of selected_mode, input
* and output shaft speeds, and driver selections (dcc_manual_input).
* Shift parameters are in the data structure shf_tbl. Before setting
* destination_gear_selected, gears are checked with available_gear().
*
* Part Number:  <none>
*
* $Log:  R:\ashift\vcs\sel_gear.c9v $
*
* Rev 1.8  21 Feb 1994 15:07:14  schroeder
* Replaced shiftability_mode with new flag, engine_brake_available.
*
* Rev 1.0  29 Jul 1993 16:40:26  schroeder
* Initial revision.
*
*****/

/*****
*
* Header files included.
*
*****/

#include <exec.h>          /* executive information */
#include <c_regs.h>         /* c registers */
#include <wwslib.h>        /* contains common global defines */
#include "cont_sys.h"      /* control system */
#include "conj1939.h"      /* defines interface to j1939 control module */
#include "drl_cmds.h"      /* driveline commands information */
#include "sel_gear.h"       /* select gear */
#include "shf_tbl.h"        /* shift table definition */
#include "trn_tbl.h"        /* (system) transmission table definition */
#include "calc_spd.h"
#include "trns_act.h"
#pragma noreentrant

/*****
*
* #defines local to this file.
*
*****/

#define US_PER_LOOP 40000U

#define INITIAL_START_GEAR 1

/*****
*
* Constants and variables declared by this file.
*
*****/

/* public */

char destination_gear_selected;
char destination_gear;
char flash_desired_allowed;
char desired_gear;
char desired_gear_dn;      /* debug use - delete later */
char desired_gear_up;      /* debug use - delete later */
uchar coasting_latch;
uchar sel_gear_cntr1;      /* debug use - delete later */
uchar sel_gear_cntr2;      /* debug use - delete later */
uchar sel_gear_cntr3;      /* debug use - delete later */

```

```

uchar shift_init_type;
uint lpf_output_speed;
int dos_predicted;          /* BIN 0 */
int dos_prdtd_lim_no_jake;  /* BIN 0 */

/* local */

/* filter weights for the "mda" output speed filter */
static register uchar w1;
static register uchar w2;
static register uchar w3;
static register uchar w4;

/* shift table (define and extern in shf_tbl.h) */
struct shf_tbl_t shf_tbl;

/* default shift table values */
const struct shf_tbl_t ini_shf_tbl =
(
    1200,          /* aut_dwn_rpm */
    1000,          /* aut_min_dwn_rpm */
    1700,          /* aut_up_rpm */
    0,             /* best_gr_offset */
    50,            /* dwn_offset_rpm */
    100,           /* dwn_reset_rpm */
    400,           /* dwn_timer_offset_rpm */
    40,            /* hysteresis_rpm */
    1850,          /* man_dwn_sync_rpm */
    700,           /* man_up_sync_rpm */
    1900,          /* rated_rpm */
    150,           /* up_offset_rpm */
    125,           /* up_reset_rpm */
    200,           /* up_timer_offset_rpm */
    0,             /* dwn_accel */
    8,             /* up_accel */
    3000,          /* offset_time */
    (uint)(0.25*256), /* aut_up_pct */
    10,            /* min_output_spd */
    1,             /* max_start_gear */
    0,             /* padbyte1 */

    196,           /* k1_ability, min-ft/rev-sec, BIN 12 */
    431,           /* axle_ratio_cal, BIN 7 */
    383,           /* gcw_k1, rev/sec-min-ft, BIN 0 */
    2437,          /* gcw_k2, rev/sec^2, BIN 7 */
    1325,          /* calc_start_point, rpm, BIN 0 */

    107,           /* k6_ability, min-lb-ft-sec/rev, BIN 8 */
    1500,          /* auto_up_lo_base, rpm, BIN 0 */
    1100,          /* auto_dn_lo_base, rpm, BIN 0 */
    100,           /* auto_rtd_offset, rpm, BIN 0 */
    1000,          /* lowest_engage_rpm, BIN 0 */
    0,             /* padword1 */
    0,             /* padword2 */
);

/* local -- initialized at start of task by select_gear */

/* shift points with anti-hunt offsets; referenced by auto_downshift and
   auto_upshift; set by get_automatic_gear and select_gear */
uint upshift_point;
uint downshift_point;

/* lower limit for gear selections */
char lowest_forward;

/* indicate direction of a get_automatic_gear shift; referenced by
   get_manual_gear; cleared by select_gear when shift complete */
char automatic_sip;

/* used in the determination of shift_points based on throttle position */
static uint auto_up_rpm;
static uint auto_dn_rpm;
static uint auto_up_offset_rpm;
static uint auto_dn_offset_rpm;

/* delay counter for anti-hunt */
static uchar antihunt_counter;

```

/* gross combined weight calculations */

```
#define ZERO_SPEED_TIME_LIMIT 4500 /* 3 min @ 0.040 period */
#define VALID_OLD_DATA_TIME 100 /* 4 sec @ 0.040 period */
#define MAX_VEHICLE_WEIGHT 100000 /* 100,000 lbs */
#define DOS_OFFSET_INIT 48
#define ENG_DECEL_LOW_LIMIT -350 /* rpm/s */
#define ENG_DECEL_LPF 224 /*  $\exp(-2\pi(0.53\text{Hz})(0.040\text{s})) = 0.875$  (BIN 8) */
```

#pragma eject


```

/*****
 *
 * Function: mda_output_filter
 *
 * Description:
 *   This is a one pole LPF with a variable coefficient. The magnitude
 *   of the coefficient is directly related to the acceleration content
 *   of the speed sample and the frequency.
 *
 *****/

static void mda_output_filter(void)
(
    #define K1 8
    #define K2 24
    #define K3 48
    #define K4 160

    static register uint os_delta_speed;
    static register uchar weight;

    if (lpf_output_speed > output_speed)
        os_delta_speed = lpf_output_speed - output_speed;
    else
        os_delta_speed = output_speed - lpf_output_speed;

    if (os_delta_speed <= K1)          /* delta <= 200 rpm/s */
    (
        if (w1 > 1) --w1;
        if (w2 < 5) ++w2;
        if (w3 < 6) ++w3;
        if (w4 < 7) ++w4;
        weight = w1;
    )
    else if (os_delta_speed <= K2)      /* 200 rpm/s < delta <= 600 rpm/s */
    (
        if (w1 < 4) ++w1;
        if (w2 > 2) --w2;
        if (w3 < 6) ++w3;
        if (w4 < 7) ++w4;
        weight = w2;
    )
    else if (os_delta_speed <= K3)      /* 600 rpm/s < delta <= 1200 rpm/s */
    (
        if (w1 < 4) ++w1;
        if (w2 < 5) ++w2;
        if (w3 > 3) --w3;
        if (w4 < 7) ++w4;
        weight = w3;
    )
    else if (os_delta_speed <= K4)      /* 1200 rpm/s < delta <= 4000 rpm/s */
    (
        if (w1 < 4) ++w1;
        if (w2 < 5) ++w2;
        if (w3 < 6) ++w3;
        if (w4 > 3) --w4;
        weight = w4;
    )
    else                                /* 4000 rpm/s < delta */
    (
        if (w1 < 4) ++w1;
        if (w2 < 5) ++w2;
        if (w3 < 6) ++w3;
        if (w4 < 7) ++w4;
        weight = 7;
    )

    lpf_output_speed = lpf_output_speed +
        (output_speed >> weight) - (lpf_output_speed >> weight);
)

#pragma eject

```

```

/*****
 *
 * Function: new_input_speed
 *
 * Description:
 *   A utility function that returns the input shaft speed expected if
 *   "gear" was engaged with the present output shaft speed.
 *
 *****/

```

```

static uint new_input_speed(char gear)

```

```

{
    /* new_input_speed = lpf_output_speed * gear_ratio */
    _ax = trn_tbl.gear_ratio[gear + GR_OFS];          /* BIN 8 */
    asm mulu _axbx, lpf_output_speed;                 /* BIN 0+8=8 (_axbx) */
    asm shrl _axbx, #8;                                /* BIN 8>>=0 (_ax) */
    return _ax;
}

```

```

#pragma eject

```

```

/*****
 *
 * Function: auto_upshift
 *
 * Description:
 *   This boolean function returns true when automatic upshift
 *   conditions have been met.
 *
 *****/

```

```

static int auto_upshift(void)
{
  /* if (input_speed > upshift_point) */
  if ((gos > upshift_point) && (output_speed_filtered > 120))
  {
    if (engine_communication_active)
    {
      /* if ((!shiftability_hold) && (!shiftability_hold_II)) */
      sel_gear_cntr2++;
      return 1;
    }
  }
  return 0;
}

```

```

#pragma eject

```

```

/*****
 *
 * Function: auto_downshift
 *
 * Description:
 *   This boolean function returns true when automatic downshift
 *   conditions have been met.
 *
 *****/

static int auto_downshift(void)
{
  /* if (input_speed < downshift_point) */
  if (gos < downshift_point)
  {
    return 1;
  }
  return 0;
}
#pragma eject

```

```

/*****
 *
 * Function:  determine_autosplit_type
 *
 * Description:
 *   This function is used to determine if the impending shift type is
 *   MANUAL or AUTO.
 *****/

static char determine_autosplit_type(char passed_new_gear, char passed_initial_gear)
{
    register char new_gr = passed_new_gear;
    register char init_gr = passed_initial_gear;

    if ((shift_in_process == FALSE) || (engine_status == ENGINE_RECOVERY_MODE))
    {
        if ((new_gr == 1 && init_gr == 2) || /* dn */
            (new_gr == 3 && init_gr == 4) || /* dn */
            (new_gr == 5 && init_gr == 6) || /* dn */
            (new_gr == 7 && init_gr == 8) || /* dn */
            (new_gr == 9 && init_gr == 10) || /* dn */
            (new_gr == 10 && init_gr == 9) || /* up */
            (new_gr == 8 && init_gr == 7) || /* up */
            (new_gr == 6 && init_gr == 5) || /* up */
            (new_gr == 4 && init_gr == 3) || /* up */
            (new_gr == 2 && init_gr == 1)) /* up */
            shift_init_type = AUTO;

        else
            shift_init_type = MANUAL;
    }

    if ((init_gr <= 4) && (new_gr < init_gr))
        shift_init_type = MANUAL; /* prevent coasting auto downshifts in low gears */
}

#pragma eject

```

```

/*****
*
* Function: get_automatic_gear
*
* Description:
*   This function returns an "automatic" forward gear selection. It
*   also performs driver requested shifts (manual_request) restricted
*   by shaft speeds. If no gears are available in required direction,
*   initial_gear is returned.
*
*****/

```

```

static char get_automatic_gear(char initial_gear, char manual_request)
(

```

```

    register char new_gear = initial_gear;

```

```

    if (automatic_sip != -1)
    (

```

```

        sel_gear_cntr3++;

```

```

        /* initiate or continue an automatic upshift: search up from lowest_forward
        (fastest input speed) for the first available gear that will provide input
        speed below a value (approx upshift rpm, minus an offset for gears that will
        result in a net downshift) */
        for (new_gear = lowest_forward;
            (new_input_speed(new_gear) > (upshift_point -
                (new_gear < initial_gear ?
                    (shf_tbl.up_offset_rpm + auto_dn_offset_rpm) : shf_tbl.best_gr_offset)))
            && (new_gear <= trn_tbl.highest_forward);
            ++new_gear)
        ;

```

```

        /* if we ran out of gears and the highest is available, it must be due to speed;
        pick highest_forward, input speed will be slower than it is now */
        if (new_gear > trn_tbl.highest_forward)
            new_gear = trn_tbl.highest_forward;

```

```

        desired_gear = new_gear;
        desired_gear_up = new_gear;
        determine_autosplit_type(new_gear, initial_gear);

```

```

        /* if in gear manual or the selection will underspeed, pick initial_gear */
        if (((shift_init_type == MANUAL) && (transmission_position == IN_GEAR)) ||
            ((automatic_sip == 0) && (new_gear <= initial_gear)))
            new_gear = initial_gear;

```

```

        else
        (
            /* indicate gear change and adjust downshift_point */
            automatic_sip = +1;
            auto_up_offset_rpm = 0;
            if (shift_init_type == AUTO)
                auto_dn_offset_rpm = shf_tbl.dwn_timer_offset_rpm;
            else
                auto_dn_offset_rpm = 0;
        )
    )

```

```

    if ((automatic_sip != 1) && (initial_gear > lowest_forward))
    (

```

```

        /* initiate or continue an automatic downshift: search down from
        highest_forward (slowest input speed) for the first available gear that will
        provide input speed above a value (approx downshift rpm, plus an offset for
        gears that will result in a net upshift) */
        for (new_gear = trn_tbl.highest_forward;
            (new_input_speed(new_gear) < (downshift_point +
                (new_gear > initial_gear ? shf_tbl.dwn_offset_rpm : shf_tbl.best_gr_offset)))
            && (new_gear >= lowest_forward);
            --new_gear)
        ;

```

```

        /* if we ran out of gears and the lowest is available, it must be due to speed;
        pick lowest_forward, input speed will be faster than it is now */
        if (new_gear < lowest_forward)
            new_gear = lowest_forward;

```

```

        desired_gear_dn = new_gear;

```

```

        if (desired_gear_dn < initial_gear) /* must be a down shift or else it */

```

gear
 upshift
 downshift
 use
 initial
 gear

also need
 current gear
 + 1 offset
 to indicate
 upshift
 (+1)

same for
 downshift
 -1

```

    desired_gear = new_gear;          /* wrongly cancel the desired_up pick. */
    determine_autosplit_type(new_gear, initial_gear);

    /* if in gear manual or the selection will overspeed, pick initial_gear */
    if (((shift_init_type == MANUAL) && (transmission_position == IN_GEAR)) ||
        ((automatic_sip == 0) && (new_gear >= initial_gear)))
        new_gear = initial_gear;
    else
    {
        /* indicate automatic gear change and adjust upshift_point */
        automatic_sip = -1;
        auto_dn_offset_rpm = 0;
        if (shift_init_type == AUTO)
            auto_up_offset_rpm = shf_tbl.up_timer_offset_rpm;
        else
            auto_up_offset_rpm = 0;
    }
}
return new_gear;
}

#if (0)
**** This is the select gear based on AutoShift code ****
#pragma eject

```

```

/*****
*
* Function: get_automatic_gear
*
* Description:
*   This function returns an "automatic" forward gear selection. It
*   also performs driver requested shifts (manual_request) restricted
*   by shaft speeds. If no gears are available in required direction,
*   initial_gear is returned.
*
*****/

static char get_automatic_gear(char initial_gear, char manual_request)
(
    register char new_gear = initial_gear;

    if (((automatic_sip == 0) && auto_upshift()) || (automatic_sip > 0))
    (
        sel_gear_cntr3++;

        /* initiate or continue an automatic upshift: search up from lowest_forward
        (fastest input speed) for the first available gear that will provide input
        speed below a value (approx upshift rpm, minus an offset for gears that will
        result in a net downshift) */
        for (new_gear = lowest_forward;
            (new_input_speed(new_gear) > (upshift_point -
                (new_gear < initial_gear ?
                    (shf_tbl.up_offset_rpm + auto_dn_offset_rpm) : shf_tbl.best_gr_offset)))
            && (new_gear <= trn_tbl.highest_forward);
            ++new_gear)
        ;

        /* if we ran out of gears and the highest is available, it must be due to speed;
        pick highest forward, input speed will be slower than it is now */
        if (new_gear > trn_tbl.highest_forward)
            new_gear = trn_tbl.highest_forward;

        desired_gear = new_gear;
        determine_autosplit_type(new_gear, initial_gear);

        /* if in gear manual or the selection will underspeed, pick initial_gear */
        if ((shift_init_type == MANUAL) && (transmission_position == IN_GEAR))
            new_gear = initial_gear;
        else
        (
            /* indicate gear change and adjust downshift_point */
            automatic_sip = +1;
            auto_up_offset_rpm = 0;
            if (shift_init_type == AUTO)
                auto_dn_offset_rpm = shf_tbl.dwn_timer_offset_rpm;
            else
                auto_dn_offset_rpm = 0;
        )
    )
    else if (((automatic_sip == 0) &&
        (auto_downshift()) &&
        (initial_gear > lowest_forward)) ||
        (automatic_sip < 0))
    (
        /* initiate or continue an automatic downshift: search down from
        highest_forward (slowest input speed) for the first available gear that will
        provide input speed above a value (approx downshift rpm, plus an offset for
        gears that will result in a net upshift) */
        for (new_gear = trn_tbl.highest_forward;
            (new_input_speed(new_gear) < (downshift_point +
                (new_gear > initial_gear ? shf_tbl.dwn_offset_rpm : shf_tbl.best_gr_offset)))
            && (new_gear >= lowest_forward);
            --new_gear)
        ;

        /* if we ran out of gears and the lowest is available, it must be due to speed;
        pick lowest forward, input speed will be faster than it is now */
        if (new_gear < lowest_forward)
            new_gear = lowest_forward;

        desired_gear = new_gear;
        determine_autosplit_type(new_gear, initial_gear);

        /* if in gear manual or the selection will overspeed, pick initial_gear */

```



```
if ((shift_init_type == MANUAL) && (transmission_position == IN_GEAR))
    new_gear = initial_gear;
else
{
    /* indicate automatic gear change and adjust upshift_point */
    automatic_sip = -1;
    auto_dn_offset_rpm = 0;
    if (shift_init_type == AUTO)
        auto_up_offset_rpm = shf_tbl.up_timer_offset_rpm;
    else
        auto_up_offset_rpm = 0;
}
}
return new_gear;
}

#endif

#pragma eject
```

```

/*****
*
* Function:  determine_destination
*
* Description:
*   This function uses "coasting_latch" to determine if a coasting or
*   skip shift is being attempted.  When sensed, the latch is used in
*   the determine_base_pts function to effect the base shift points.
*
*****/

```

```

void determine_destination(void)
(

```

```

    /* if coasting in neutral - force shift points */

```

```

    if (coasting_latch == FALSE)
    (

```

```

        if ((last_known_gear - destination_gear_selected) > 1) /* multi downshift */
        (

```

```

            if ((destination_gear_selected == 7) ||
                (destination_gear_selected == 5) ||
                (destination_gear_selected == 3) ||
                (destination_gear_selected == 1))
            (

```

```

                destination_gear_selected++;
                coasting_latch = TRUE;
            )
        )
    )

```

```

    else
    (

```

```

        if ((destination_gear_selected - last_known_gear) > 1) /* multi upshift */
        (

```

```

            if ((destination_gear_selected == 10) ||
                (destination_gear_selected == 8) ||
                (destination_gear_selected == 6) ||
                (destination_gear_selected == 4))
            (

```

```

                destination_gear_selected--;
                coasting_latch = TRUE;
            )
        )
    )

```

```

    )
    else
    (

```

```

        if (shift_in_process == FALSE)
            coasting_latch = FALSE;
    )

```

```

#pragma eject

```

```

/*****
*
* Function:  determine_manual_shift_pts
*
* Description:
*
*****/

static void determine_manual_shift_pts(void)
{
    if (coasting_latch == FALSE)
    {
        if ((last_known_gear == 1) ||
            (last_known_gear == 3) ||
            (last_known_gear == 5) ||
            (last_known_gear == 7) ||
            (last_known_gear == 9))
            auto_dn_rpm = 1325;      /* manual downshifts */

        else
            auto_up_rpm = 1375;      /* manual upshifts */
    }
}

#pragma eject

```

```

/*****
 *
 * Function:  determine_base_auto_shift_pts
 *
 * Description:
 * This function determines the base up and down shift points based on
 * the position of the throttle. These base points will be used in the
 * calculation of the upshift_point and the downshift_point.
 *
 * The anti-hunting calculations have been moved to this function since
 * these calculations are now throttle dependent.
 *****/

static void determine_base_auto_shift_pts(void)
(
    if (pct_demand_at_cur_sp > 0)
    (
        /* auto_up_rpm = shf_tbl.auto_up_lo_base +
           ((shf_tbl.aut_up_rpm - shf_tbl.auto_up_lo_base) * %throttle) */

        _cx = shf_tbl.aut_up_rpm - shf_tbl.auto_up_lo_base;
        _bx = pct_demand_at_cur_sp;
        asm mulu _cxdx, _bx;
        asm divu _cxdx, #100;
        auto_up_rpm = shf_tbl.auto_up_lo_base + _cx;

        /* check for RTD requirement */
        if (pct_demand_at_cur_sp > 90)
            auto_up_rpm += shf_tbl.auto_rtd_offset;

        /* auto_dn_rpm = shf_tbl.auto_dn_lo_base +
           ((shf_tbl.aut_dwn_rpm - shf_tbl.auto_dn_lo_base) * %throttle) */

        _cx = shf_tbl.aut_dwn_rpm - shf_tbl.auto_dn_lo_base;
        _bx = pct_demand_at_cur_sp;
        asm mulu _cxdx, _bx;
        asm divu _cxdx, #100;
        auto_dn_rpm = shf_tbl.auto_dn_lo_base + _cx;
    )
    else
    (
        auto_up_rpm = shf_tbl.auto_up_lo_base;
        auto_dn_rpm = shf_tbl.auto_dn_lo_base;
    )

    determine_manual_shift_pts();

    if (shift_in_process)
    (
        /* reset antihunt_counter */
        antihunt_counter = 0;

        /* allow the knob display to flashed any new desired gear */
        flash_desired_allowed = TRUE;
    )
    else
    (
        /* reset shift in process flags and update antihunt_counter */
        automatic_sip = 0;
        if (antihunt_counter < 255)
        (
            ++antihunt_counter;
        )
        /* flash_desired_allowed = FALSE; */

        /* look for upshift anti-hunt reset conditions */
        if ((antihunt_counter * (US_PER_LOOP/1000)) >= shf_tbl.offset_time)
        (
            /* check for last shift = upshift effects */
            if (auto_dn_offset_rpm == shf_tbl.dwn_timer_offset_rpm)
                auto_dn_offset_rpm = shf_tbl.dwn_offset_rpm;
            else if ((auto_dn_offset_rpm == shf_tbl.dwn_offset_rpm) &&
                (input_speed_filtered > auto_dn_rpm + shf_tbl.dwn_reset_rpm))
                auto_dn_offset_rpm = 0;

            /* check for last shift = downshift effects */
            if (auto_up_offset_rpm == shf_tbl.up_timer_offset_rpm)

```

```

    auto_up_offset_rpm = shf_tbl.up_offset_rpm;
else if ((auto_up_offset_rpm == shf_tbl.up_offset_rpm) &&
(input_speed_filtered > auto_up_rpm - shf_tbl.up_reset_rpm))
    auto_up_offset_rpm = 0;

```

```

/* allow the knob display to flash the desired gear */
if (((desired_gear > destination_gear_selected) && (gos < (upshift_point + 25))) ||
((desired_gear < destination_gear_selected) && (gos > (downshift_point - 25))))
    flash_desired_allowed = FALSE;
else
    flash_desired_allowed = TRUE;

```

```

)

```

```

/* set the shift points based on throttle and determined offsets */
upshift_point = auto_up_rpm + auto_up_offset_rpm;
downshift_point = auto_dn_rpm - auto_dn_offset_rpm;

```

```

/* check that the calculated shift point is reasonable */
if (upshift_point > shf_tbl.man_dwn_sync_rpm)
    upshift_point = shf_tbl.man_dwn_sync_rpm;

```

```

if (downshift_point < shf_tbl.man_up_sync_rpm)
    downshift_point = shf_tbl.man_up_sync_rpm;

```

```

)

```

```

#pragma eject

```

```

/*****
*
* Function: select_gear
*
* Description:
*   This is the root function for the periodic task SELECT_GEAR. Each
*   loop begins by checking the manual up/down buttons. Then, based on
*   selected_mode and output shaft speed, a 'get..._gear' function is
*   called to update destination_gear_selected.
*
*****/

void select_gear(void)
(
    char manual_request;          /* current manual request (+/- 1) */
    static uchar enable_gcw_calc; /* diagnostic - delete later !! */

    enable_gcw_calc = FALSE;      /* diagnostic - delete later !! */

    shf_tbl = ini_shf_tbl;        /* initialize the shift table */

    destination_gear_selected = 1;
    desired_gear = 1;

    /* initialize file scope variables */

    w1 = 3;
    w2 = 4;
    w3 = 5;
    w4 = 6;
    lpf_output_speed = output_speed;

    upshift_point = shf_tbl.aut_up_rpm;
    downshift_point = shf_tbl.aut_dwn_rpm;
    auto_up_offset_rpm = shf_tbl.up_timer_offset_rpm;
    auto_dn_offset_rpm = shf_tbl.dwn_timer_offset_rpm;
    lowest_forward = INITIAL_START_GEAR;
    automatic_sip = 0;
    antihunt_counter = 255U;
    coasting_latch = FALSE;
    flash_desired_allowed = TRUE;

    x_start_periodic();
    while (1)
    (
        mda_output_filter();      /* update our filtered output speed */
        manual_request = 0;
        determine_base_auto_shift_pts();

        /* set destination_gear_selected from function(s) appropriate for selected_mode */
        switch(selected_mode)
        (
            case REVERSE_MODE:

            case DRIVE_MODE:
                if ((forward_last == TRUE) && (low_speed_latch == FALSE))
                (
                    destination_gear_selected = get_automatic_gear(destination_gear_selected, manual_request);
                    determine_destination();
                    sel_gear_cntr1++; /* debug use only - delete later */
                )
                break;

            case LOW_MODE:
            case HOLD_MODE:
            case NEUTRAL_MODE:
            case PARK_MODE:
            case POWER_UP_MODE:
            case POWER_DOWN_MODE:
            case DIAGNOSTIC_TEST_MODE:
                /* prevent transient selection upon mode change (these modes ignore it) */
                destination_gear_selected = 0;
                break;

            default:
                /* invalid mode: do nothing */
                break;
        )
        x_sync_periodic(US_PER_LOOP);
    )
)

```

```
}  
x_end_periodic();  
}
```

```

/*****
*
*   Unpublished and confidential. Not to be reproduced,
*   disseminated, transferred or used without the prior
*   written consent of Eaton Corporation.
*
*   Copyright Eaton Corporation, 1991-94.
*   All rights reserved.
*
*****/

* Filename: seq_shft.c96      (AutoSplit)
*
* Description:
*   The functions in this file will perform the required system
*   level operations for implementing Sequence Shift.
*
* Part Number: <none>
*
* $Log:   R:\aselect\vcs\seq_shft.c9v $
*
*   Rev 1.0   12 May 1994 16:26:00   markyvech
*   Initial version
*
*****/

/*****
*
* Header files included.
*
*****/

#include <exec.h>      /* executive information */
#include <c_regs.h>     /* KR internal registers */
#include <wwslib.h>     /* World Wide Software Library */
#include "cont_sys.h"  /* control system information */
#include "conj1939.h"  /* Defines interface to engine communications info */
#include "con_o_s.h"   /* control output signal information */
#include "drl_cmds.h"  /* driveline commands information */
#include "sel_gear.h"   /* Contains information relative to engine */
#include "shf_tbl.h"   /* transmission table information */
#include "trn_tbl.h"   /* transmission information */
#include "trns_act.h"

/*****
*
* #defines local to this file.
*
*****/

/*****
*
* public.
*
*****/

uchar sq_sh1; /* debug counter - delete later */
uchar sq_sh2; /* debug counter - delete later */
uchar sq_sh3; /* debug counter - delete later */

/*****
*
* Constants and variables declared by this file.
*
*****/

static uchar coast_mode; /* allows vehicle to coast in low gears */
static uint mode_time_out; /* time to disengage or synchronize a gear */

#pragma eject

```


1

```
/******  
 *  
 * Function: initialize_sequence_shift  
 *  
 * Description:  
 *   This function initializes the variables to be used in sequence_shift.  
 *  
 *****/
```

```
void initialize_sequence_shift(void)  
{  
    shift_type = UPSHIFT;  
    shift_in_process = FALSE;  
}
```

```
#pragma eject
```

```

/*****
*
* Function: shift_initiate
*
* Description:
* This function begins the shift sequence by setting up the
* transmission to pull to Neutral, commands the electronic engine
* controller to go to zero torque and prepares the clutch to disengage
* if required.
*
*****/

static void shift_initiate(void)
(
    if (destination_gear < last_known_gear) /* determine shift type */
    (
        if (pct_demand_at_cur_sp > 5)
            shift_type = POWER_DOWN_SHIFT;
        else
            shift_type = COAST_DOWN_SHIFT;
    )
    else
        shift_type = UPSHIFT;

    /* Attempt to get out of gear for 3 seconds then return fuel to driver */
/*
    if ( (engine_status != ENGINE_PREDIP_MODE) && (mode_time_out > 0) )
        mode_time_out = 300;
    if ( (mode_time_out > 0) && (!coast_mode) )
        --mode_time_out;
*/
    mode_time_out = 300; /* force value for now */

    /* initiate a normal shift sequence */

    /* (do not request engine fueling with engine brake on) */
    eng_brake_command = ENG_BRAKE_OFF; /* eng brake: zero torque */

    if ((lpf_output_speed < shf_tbl.min_output_spd) ||
        (clutch_state == DISENGAGED) ||
        (mode_time_out == 0) ||
        ((destination_gear < 4) &&
         (coast_mode) &&
         (accelerator_pedal_position <= 5) &&
         (shift_type != UPSHIFT)))
    (
        engine_commands = ENGINE_FOLLOWER;
    )
    else
    (
        engine_commands = ENGINE_PREDIP; /* engine: bring torque to zero */
        coast_mode = FALSE;
    )
)

#pragma eject

```

```

/*****
*
* Function: synchronize_gear
*
* Description:
* This function assists the synchronizing of the transmission if
* possible, by controlling input shaft speed through the use
* of the clutch, power synchronizer, or inertia brake. It will
* offset sync windows if the shift is taking longer than expected.
* It will assist with engagement at rest if the clutch is dragging.
*
*****/

static void synchronize_gear(void)
(
    /* turn on engine brakes (J1939) if engine brake assisted shift is requested */

    if (eng_brake_assist)
        eng_brake_command = ENG_BRAKE_FULL;
    else
        eng_brake_command = ENG_BRAKE_OFF;

    /* Attempt to engage for 6 seconds then return fuel control to the driver */
    /*
    if ( (engine_status != ENGINE_SYNC_MODE) && (mode_time_out > 0) )
        mode_time_out = 600;
    if ( (mode_time_out > 0) && (!coast_mode) )
        --mode_time_out;
    */
    mode_time_out = 600; /* force value for now */

    if ((lpf_output_speed < shf_tbl.min_output_spd) ||
        (clutch_state == DISENGAGED) ||
        (mode_time_out == 0) ||
        ((destination_gear < 4) &&
         (coast_mode) &&
         (accelerator_pedal_position <= 5) &&
         (shift_type != UPSHIFT)))
    (
        engine_commands = ENGINE_FOLLOWER;
    )

    else
    (
        engine_commands = ENGINE_SYNC;
        coast_mode = FALSE;
    )
)

#pragma eject

```

```

/*****
*
* Function: confirm_shift
*
* Description:
*   This function finished the shift; shift_in_process is set FALSE.
*
*****/

static void confirm_shift(void)
{
    engine_commands = ENGINE_RECOVERY;    /* engine: finish torque return */
    eng_brake_command = ENG_BRAKE_OFF;    /* eng brake: zero torque */
    mode_time_out = 300;                  /* reset for next shift */
    shift_in_process = FALSE;
    coast_mode = TRUE;
}

#pragma eject

```

```

/*****
*
* Function: sequence_shift
*
* Description:
* This function calls the appropriate procedures to perform the
* operations of Sequence_Shift depending on the correct state of
* the shift process.
*
*****/

void sequence_shift(void)
{
    if (destination_gear == NULL_GEAR) /* system has reset: do not start a shift */
    {
        engine_commands = ENGINE_FOLLOWER;
        eng_brake_command = ENG_BRAKE_IDLE;
    }

    else
        if (((transmission_position == OUT_OF_GEAR) &&
            ((engine_status == ENGINE_SYNC_MODE) ||
            (engine_status == ENGINE_PREDIP_MODE))) /* forces call shift_initiate() */
        {
            sq_sh1++;
            synchronize_gear();
        }

        else
            if (((engine_status == ENGINE_SYNC_MODE) ||
                (engine_status == ENGINE_RECOVERY_MODE)) &&
                (destination_gear == current_gear) &&
                (transmission_position == IN_GEAR))
            {
                sq_sh2++;
                confirm_shift();
            }

            else
                if (((destination_gear != current_gear) && /* auto splitter */
                    (low_speed_latch == FALSE) &&
                    (automatic_sip != 0) &&
                    (transmission_position == IN_GEAR)) ||
                    ((transmission_position == OUT_OF_GEAR) && /* manual shift */
                    (low_speed_latch == FALSE)))
                {
                    shift_initiate();
                    sq_sh3++;
                }
}

```

```

/*****
 *
 *      Unpublished and confidential. Not to be reproduced,
 *      disseminated, transferred or used without the prior
 *      written consent of Eaton Corporation.
 *
 *      Copyright Eaton Corporation, 1994.
 *      All rights reserved.
 *
 *****/

 *
 * Filename: trns_act.c96      (AutoSplit)
 *
 * Description:
 * This modules monitors and controls the transmission actions.
 *
 * Part Number: <none>
 *
 * $Log:   ??? $
 *
 *      Rev 1.0   3 May 1994 13:35:04   markyvech
 *      Initial revision.
 *
 *****/
/*****
 *
 * Header files included.
 *
 *****/

#include <exec.h>          /* executive information */
#include <c_regs.h>         /* KR internal register definitions */
#include <kr_sfr.h>        /* defines the kr special function registers */
#include <kr_def.h>        /* 80c196kr bits, constants, and structures */
#include <wwslib.h>
#include "drl_cmds.h"      /* engine control interface */
#include "trns_act.h"      /* interface to this module */
#include "trn_tbl.h"       /* transmission table */
#include "calc_spd.h"
#include "cont_sys.h"
#include "sel_gear.h"
#include "conj1939.h"

/*****
 *
 * Variables declared by this file.
 *
 *****/

register unsigned char  transmission_position;

unsigned char  low_speed_latch;
unsigned char  forward_last;
unsigned char  splitter_hi;
unsigned char  splitter_lo;
unsigned char  splitter_timer;
unsigned char  splitter_within_sync;
unsigned char  aux_box;
signed char   g_ptr_old;
signed char   current_gear;
signed char   last_known_gear;
unsigned int  gear_in_timer;
unsigned int  gear_out_timer;
unsigned int  abs_trans_sync_error;
unsigned int  trans_window_calc;
signed int   input_speed_modified;
signed int   trans_sync_error;
signed int   range_error;
signed int   range_cal;
signed int   splitter_tc;

signed long   isdgf;
signed long   gros;
signed char   g_ptr;

#pragma eject

```

```

/*****
*
* #defines and constants local to this file.
*
*****/

```

```

#define US_PER_LOOP 10000U
#define RKM_US_PER_LOOP 40000U

```

```

static const uchar SPLITTER_LO_TABLE[23] =

```

```

(
    0,      /* -4 */
    0,      /* -3 */
    ON,     /* -2 */ /* split_lo = OFF, split_hi = ON; overdrive */
    ON,     /* -1 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 0 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 1 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 2 */ /* split_lo = OFF, split_hi = ON; overdrive */
    ON,     /* 3 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 4 */ /* split_lo = OFF, split_hi = ON; overdrive */
    ON,     /* 5 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 6 */ /* split_lo = OFF, split_hi = ON; overdrive */
    ON,     /* 7 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 8 */ /* split_lo = OFF, split_hi = ON; overdrive */
    ON,     /* 9 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 10 */ /* split_lo = OFF, split_hi = ON; overdrive */
    0,      /* 11 */
    0,      /* 12 */
    0,      /* 13 */
    0,      /* 14 */
    0,      /* 15 */
    0,      /* 16 */
    0,      /* 17 */
    0       /* 18 */
);

```

```

static const uchar SPLITTER_HI_TABLE[23] =

```

```

(
    0,      /* -4 */
    0,      /* -3 */
    ON,     /* -2 */ /* split_lo = OFF, split_hi = ON; overdrive */
    OFF,    /* -1 */ /* split_lo = ON, split_hi = OFF; direct */
    OFF,    /* 0 */ /* split_lo = ON, split_hi = OFF; direct */
    OFF,    /* 1 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 2 */ /* split_lo = OFF, split_hi = ON; overdrive */
    OFF,    /* 3 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 4 */ /* split_lo = OFF, split_hi = ON; overdrive */
    OFF,    /* 5 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 6 */ /* split_lo = OFF, split_hi = ON; overdrive */
    OFF,    /* 7 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 8 */ /* split_lo = OFF, split_hi = ON; overdrive */
    OFF,    /* 9 */ /* split_lo = ON, split_hi = OFF; direct */
    ON,     /* 10 */ /* split_lo = OFF, split_hi = ON; overdrive */
    0,      /* 11 */
    0,      /* 12 */
    0,      /* 13 */
    0,      /* 14 */
    0,      /* 15 */
    0,      /* 16 */
    0,      /* 17 */
    0       /* 18 */
);

```

```

#pragma eject

```

```

static const uchar SPLITTER_TC_TABLE[23] =
{
    0,      /* -4 */
    0,      /* -3 */
    100,    /* -2 */ /* splitter = overdrive */
    100,    /* -1 */ /* splitter = direct */
    100,    /* 0 */ /* splitter = direct */
    100,    /* 1 */ /* splitter = direct */
    100,    /* 2 */ /* splitter = overdrive */
    100,    /* 3 */ /* splitter = direct */
    100,    /* 4 */ /* splitter = overdrive */
    100,    /* 5 */ /* splitter = direct */
    100,    /* 6 */ /* splitter = overdrive */
    100,    /* 7 */ /* splitter = direct */
    100,    /* 8 */ /* splitter = overdrive */
    100,    /* 9 */ /* splitter = direct */
    100,    /* 10 */ /* splitter = overdrive */
    0,      /* 11 */
    0,      /* 12 */
    0,      /* 13 */
    0,      /* 14 */
    0,      /* 15 */
    0,      /* 16 */
    0,      /* 17 */
    0,      /* 18 */
};

#pragma eject

```



```

/*****
*
* Function: Initialize_Trans_Action
*
* Description:
*   This function initializes those module variables that must be set to a
*   know state on power up or reset.
*
*****/

void initialize_trans_action(void)
{
    gear_in_timer = 200;
    gear_out_timer = 200;
    g_ptr_old = 0;
    current_gear = 0;
    last_known_gear = 0;
    destination_gear = 0;
    transmission_position = OUT_OF_GEAR;
    low_speed_latch = TRUE;
    splitter_lo = 0;
    splitter_hi = 0;
}

#pragma eject

```

```

/*****
*
* Function:  determine_gear
*
* Description:
* This function determines the current gear that the transmission
* is in.  When conditions are such that the current gear can not be
* determined it will be set to a default,(0).
*
* Note: When the error across the transmission is near zero for some
* time for a given test gear then it will be deemed in that gear.
*
*          error = input_spd/gf[gear] - gr[gear] * os
*
*****/
void determine_gear(void)
(
#define BIN_8          256      /* 2 BIN 8 */
#define MAX_ERR        4000     /* RPM */
#define WINDOW         30      /* 30 RPM */
#define GEAR_IN_TIME_LEVER 30    /* 300 MSEC */
#define GEAR_IN_TIME_AUTO 20    /* 200 MSEC */
#define GEAR_OUT_TIME   8       /* 80 MSEC */
#define ERROR_FUDGE_FACTOR 3    /* RPM */
/*
signed long  isdgm;
signed long  gros;
signed char  g_ptr;
*/

#if (0)
    g_ptr = -1; /* lowest reverse ratio */

/*  isdgm = (((signed long) input_speed_filtered) * BIN_8) / trn_tbl.GF[g_ptr + GR_OFS]; */
    _bx = (signed int)(input_speed_filtered);
    _cx = BIN_8;
    _ax = trn_tbl.GF[g_ptr + GR_OFS];
    asm mul _cxdx, _bx;
    asm div _cxdx, _ax;
    isdgm = _cx;

/*  gros = (((signed long) output_speed_filtered) * trn_tbl.GR[g_ptr + GR_OFS]) / BIN_12; */
    _bx = (signed int)(output_speed_filtered + ERROR_FUDGE_FACTOR);
    _cx = trn_tbl.GR[g_ptr + GR_OFS];
    _ax = BIN_8;
    asm mul _cxdx, _bx;
    asm div _cxdx, _ax;
    gros = _cx;

    trans_sync_error = (isdgm - gros);
    if (isdgm > gros)
        abs_trans_sync_error = (unsigned int)(isdgm - gros);
    else
        abs_trans_sync_error = (unsigned int)(gros - isdgm);
#endif

    abs_trans_sync_error = MAX_ERR;
    trans_window_calc = 0;

    if (abs_trans_sync_error > trans_window_calc) /* if not in reverse, check for forward */
    (
        g_ptr = 1 + trn_tbl.highest_forward;
        abs_trans_sync_error = MAX_ERR;
        while ((abs_trans_sync_error > trans_window_calc) && (g_ptr != 0))
        (
            g_ptr--;
            /*  isdgm = (((signed long) input_speed_filtered) * BIN_8) / trn_tbl.GF[g_ptr + GR_OFS]; */
            _bx = (signed int)(input_speed_filtered);
            _cx = BIN_8;
            _ax = trn_tbl.GF[g_ptr + GR_OFS];
            asm mul _cxdx, _bx;
            asm div _cxdx, _ax;
            isdgm = _cx;

            /*  gros = (((signed long) output_speed_filtered) * trn_tbl.GR[g_ptr + GR_OFS]) / BIN_12; */
            _bx = (signed int)(output_speed_filtered + ERROR_FUDGE_FACTOR);
            _cx = trn_tbl.GR[g_ptr + GR_OFS];

```

```

_ax = BIN_8;
asm mul _cxdx, _bx;
asm div _cxdx, _ax;
gros = _cx;

trans_sync_error = isdgf - gros;
if (isdgf > gros)
    abs_trans_sync_error = (int)(isdgf - gros);
else
    abs_trans_sync_error = (int)(gros - isdgf);

/* calculate trans sync error window based on gear pointer */
_bx = WINDOW; /* BIN 0 */
_cx = BIN_8; /* BIN 8 */
_ax = trn_tbl.GF[g_ptr + GR_OFS]; /* BIN 8 */
asm mulu _cxdx, _bx; /* make WINDOW BIN 8 */
asm divu _cxdx, _ax; /* divide by front ratio BIN 8 */
trans_window_calc = _cx; /* BIN 0 */
}

if (g_ptr == 0) /* If in neutral, force values */
{
    abs_trans_sync_error = MAX_ERR;
    trans_sync_error = MAX_ERR;
    trans_window_calc = 0;
    isdgf = 0;
    gros = 0;
}

if ((abs_trans_sync_error > trans_window_calc) || /* Must have error for some */
    ((g_ptr != current_gear) && (current_gear != 0))) /* before neutral state is */
{ /* recognized. */
    if (gear_out_timer == 0)
    {
        transmission_position = OUT_OF_GEAR;
        current_gear = 0;
    }

    else
        gear_out_timer--;
}
else
    gear_out_timer = GEAR_OUT_TIME;

if ((g_ptr != g_ptr_old) || (g_ptr == 0) || /* if not in gear, init gear in timer. */
    ((accelerator_pedal_position < 5) && /* Rule out picking a gear when coasting */
    (input_speed < 800) && /* down in neutral and no throttle. */
    (low_speed_latch == FALSE))) /* (Found that idle speed and output speed */
/* would natch a gear even when in neutral.) */
{
    if ((engine_commands == ENGINE_SYNC) ||
        (engine_commands == ENGINE_PREDIP))
    {
        if (shift_init_type == AUTO)
            gear_in_timer = GEAR_IN_TIME_AUTO;
        else
            gear_in_timer = GEAR_IN_TIME_LEVER;
    }
}

else
    if (gear_in_timer == 0)
    {
        current_gear = g_ptr;
        last_known_gear = g_ptr;
        transmission_position = IN_GEAR;

        if ((gros_current_gear > (downshift_point + 100)) &&
            (low_speed_latch == TRUE))
        {
            low_speed_latch = FALSE;
            destination_gear = current_gear;
            destination_gear_selected = current_gear;
            desired_gear = current_gear;
            lowest_forward = current_gear;
        }
        else
    }

```

```

    if (low_speed_latch == TRUE)
    {
        destination_gear = lowest_forward; /* was set to 1 */
        destination_gear_selected = lowest_forward; /* was set to 1 */
        desired_gear = lowest_forward; /* was set to 1 */
        shift_in_process = FALSE;
    }
}

if (last_known_gear > 0) /* Record REV/FOR data for */
    forward_last = TRUE; /* use in the select_gear */
else /* module. */
    forward_last = FALSE;
}
else
    gear_in_timer--;

g_ptr_old = g_ptr ;

if (output_speed_filtered < 80) /* If stopped - current_gear = first. */
{
    current_gear = 0 ;
    transmission_position = OUT_OF_GEAR;
    low_speed_latch = TRUE;
}
}

#pragma eject

```

```

/*****
 *
 * Function:  determine_range_status
 *
 * Description:
 * This function determines the status the of range.
 *
 * rng_err = rear_counter_spd - (range_ratio * output_spd)
 *
 * rcs = 54/21 * 44 * os (for low range)
 *
 * rcs = 42/51 * 44 * os (for high range)
 *
 *****/

void determine_range_status(void)
(
#define BIN_12          4096  /* 2 bin 12 */
#define HI_RANGE_GEAR    7
#define LO_RANGE_CAL     10532 /* 54/21 BIN 12 */
#define HI_RANGE_CAL     3373  /* 42/51 BIN 12 */
#define RANGE_WINDOW_POS  30    /* 30 RPM */
#define RANGE_WINDOW_NEG -30    /* -30 RPM */

    if (destination_gear >= HI_RANGE_GEAR)
        range_cal = HI_RANGE_CAL;
    else
        range_cal = LO_RANGE_CAL;

    range_error = (((aux_speed * BIN_12)
        - (range_cal * output_speed_filtered))/BIN_12);

    if ((range_error > RANGE_WINDOW_POS) || (range_error < RANGE_WINDOW_NEG))
        aux_box = OUT_OF_GEAR;
    else
        aux_box = IN_GEAR;
)

#pragma eject

```

```

/*****
 *
 * Function: determine_splitter
 *
 * Description:
 * This function determines the correct state for the splitter.
 * Once the transmission is in gear both splitter solenoids are turned off.
 *
 *****/

void determine_splitter_state(void)
(
#define SPLTR_SYNC_OFFSET_POS    80    /* 80 RPM */
#define SPLTR_SYNC_OFFSET_NEG   -80    /* -80 RPM */
#define SPLITTER_TIME           20    /* 200 MSEC */

    if (engine_status == ENGINE_PREDIP_MODE)
        splitter_timer = SPLITTER_TIME;
    else
        if (splitter_timer > 0)
            splitter_timer--;

    splitter_tc = SPLITTER_TC_TABLE[destination_gear + GR_OFS];
    input_speed_modified = (signed int)(input_speed_filtered) +
        (input_speed_accel_filtered/(1000/splitter_tc));

    if ((input_speed_modified < (gos_signed + SPLTR_SYNC_OFFSET_POS)) &&
        (input_speed_modified > (gos_signed + SPLTR_SYNC_OFFSET_NEG)))
        splitter_within_sync = TRUE;
    else
        splitter_within_sync = FALSE;

    if ((splitter_timer > 0) ||
        ((transmission_position == IN_GEAR) &&
         (shift_in_process == FALSE)) || /* debug - delete later */
        (low_speed_latch == TRUE) ||
        (engine_status == ENGINE_RECOVERY_MODE) ||
        ((shift_init_type == MANUAL) &&
         (engine_status == ENGINE_SYNC_MODE)) ||
        ((shift_init_type == AUTO) &&
         (engine_status == ENGINE_SYNC_MODE) &&
         (splitter_within_sync == TRUE)))
    (
        splitter_hi = SPLITTER_HI_TABLE[destination_gear + GR_OFS];
        splitter_lo = SPLITTER_LO_TABLE[destination_gear + GR_OFS];
    )
    else
    (
        splitter_hi = OFF;
        splitter_lo = OFF;
    )
)

#pragma eject

```

```

/*****
*
* Function: Transmission_Action
*
* Description:
*   This function controls the states of the system output devices.
*
*****/
void transmission_action(void)
{
    initialize_trans_action();    /* initialize variables */

    x_start_periodic();
    while (1)
    {
        determine_gear();        /* calculate the current gear */
        determine_range_status(); /* determine range state */
        determine_splitter_state(); /* determine correct state for splitter */

        x_sync_periodic(US_PER_LOOP);
    }
    x_end_periodic();
}

```

**This Page is Inserted by IFW Indexing and Scanning
Operations and is not part of the Official Record**

BEST AVAILABLE IMAGES

Defective images within this document are accurate representations of the original documents submitted by the applicant.

Defects in the images include but are not limited to the items checked:

- ☐ **BLACK BORDERS**
- ☐ **IMAGE CUT OFF AT TOP, BOTTOM OR SIDES**
- ☒ **FADED TEXT OR DRAWING**
- ☐ **BLURRED OR ILLEGIBLE TEXT OR DRAWING**
- ☐ **SKewed/SLANTED IMAGES**
- ☐ **COLOR OR BLACK AND WHITE PHOTOGRAPHS**
- ☐ **GRAY SCALE DOCUMENTS**
- ☐ **LINES OR MARKS ON ORIGINAL DOCUMENT**
- ☐ **REFERENCE(S) OR EXHIBIT(S) SUBMITTED ARE POOR QUALITY**
- ☐ **OTHER:** _____

IMAGES ARE BEST AVAILABLE COPY.

As rescanning these documents will not correct the image problems checked, please do not report these problems to the IFW Image Problem Mailbox.